



This is a digital copy of a book that was preserved for generations on library shelves before it was carefully scanned by Google as part of a project to make the world's books discoverable online.

It has survived long enough for the copyright to expire and the book to enter the public domain. A public domain book is one that was never subject to copyright or whose legal copyright term has expired. Whether a book is in the public domain may vary country to country. Public domain books are our gateways to the past, representing a wealth of history, culture and knowledge that's often difficult to discover.

Marks, notations and other marginalia present in the original volume will appear in this file - a reminder of this book's long journey from the publisher to a library and finally to you.

Usage guidelines


Google is proud to partner with libraries to digitize public domain materials and make them widely accessible. Public domain books belong to the public and we are merely their custodians. Nevertheless, this work is expensive, so in order to keep providing this resource, we have taken steps to prevent abuse by commercial parties, including placing technical restrictions on automated querying.

We also ask that you:

- + *Make non-commercial use of the files* We designed Google Book Search for use by individuals, and we request that you use these files for personal, non-commercial purposes.
- + *Refrain from automated querying* Do not send automated queries of any sort to Google's system: If you are conducting research on machine translation, optical character recognition or other areas where access to a large amount of text is helpful, please contact us. We encourage the use of public domain materials for these purposes and may be able to help.
- + *Maintain attribution* The Google "watermark" you see on each file is essential for informing people about this project and helping them find additional materials through Google Book Search. Please do not remove it.
- + *Keep it legal* Whatever your use, remember that you are responsible for ensuring that what you are doing is legal. Do not assume that just because we believe a book is in the public domain for users in the United States, that the work is also in the public domain for users in other countries. Whether a book is still in copyright varies from country to country, and we can't offer guidance on whether any specific use of any specific book is allowed. Please do not assume that a book's appearance in Google Book Search means it can be used in any manner anywhere in the world. Copyright infringement liability can be quite severe.

About Google Book Search

Google's mission is to organize the world's information and to make it universally accessible and useful. Google Book Search helps readers discover the world's books while helping authors and publishers reach new audiences. You can search through the full text of this book on the web at <http://books.google.com/>



the 1990s, the number of people in the UK who are employed in the public sector has increased by 1.5 million, from 2.5 million in 1980 to 4 million in 1995. The public sector has become a major employer in the UK, and its growth has been a key factor in the overall growth of the economy.

The public sector has also become a major provider of social services, and its growth has been a key factor in the overall growth of the economy. The public sector has become a major provider of social services, and its growth has been a key factor in the overall growth of the economy. The public sector has become a major provider of social services, and its growth has been a key factor in the overall growth of the economy.


The public sector has also become a major provider of social services, and its growth has been a key factor in the overall growth of the economy. The public sector has become a major provider of social services, and its growth has been a key factor in the overall growth of the economy. The public sector has become a major provider of social services, and its growth has been a key factor in the overall growth of the economy.

The public sector has also become a major provider of social services, and its growth has been a key factor in the overall growth of the economy. The public sector has become a major provider of social services, and its growth has been a key factor in the overall growth of the economy. The public sector has become a major provider of social services, and its growth has been a key factor in the overall growth of the economy.

The public sector has also become a major provider of social services, and its growth has been a key factor in the overall growth of the economy. The public sector has become a major provider of social services, and its growth has been a key factor in the overall growth of the economy. The public sector has become a major provider of social services, and its growth has been a key factor in the overall growth of the economy.

The public sector has also become a major provider of social services, and its growth has been a key factor in the overall growth of the economy. The public sector has become a major provider of social services, and its growth has been a key factor in the overall growth of the economy. The public sector has become a major provider of social services, and its growth has been a key factor in the overall growth of the economy.

The public sector has also become a major provider of social services, and its growth has been a key factor in the overall growth of the economy. The public sector has become a major provider of social services, and its growth has been a key factor in the overall growth of the economy. The public sector has become a major provider of social services, and its growth has been a key factor in the overall growth of the economy.



the 1990s, the number of people with a diagnosis of schizophrenia has increased in the United Kingdom (Meltzer 1996).

There is a growing awareness of the need to improve the lives of people with mental health problems. The Department of Health (1999) has set out a vision of a new mental health system, which will be based on the principles of recovery, partnership, and choice. The vision is to create a new mental health system, which will be based on the principles of recovery, partnership, and choice. The vision is to create a new mental health system, which will be based on the principles of recovery, partnership, and choice. The vision is to create a new mental health system, which will be based on the principles of recovery, partnership, and choice.

The vision is to create a new mental health system, which will be based on the principles of recovery, partnership, and choice. The vision is to create a new mental health system, which will be based on the principles of recovery, partnership, and choice. The vision is to create a new mental health system, which will be based on the principles of recovery, partnership, and choice.

The vision is to create a new mental health system, which will be based on the principles of recovery, partnership, and choice. The vision is to create a new mental health system, which will be based on the principles of recovery, partnership, and choice. The vision is to create a new mental health system, which will be based on the principles of recovery, partnership, and choice.


The vision is to create a new mental health system, which will be based on the principles of recovery, partnership, and choice. The vision is to create a new mental health system, which will be based on the principles of recovery, partnership, and choice. The vision is to create a new mental health system, which will be based on the principles of recovery, partnership, and choice.

The vision is to create a new mental health system, which will be based on the principles of recovery, partnership, and choice. The vision is to create a new mental health system, which will be based on the principles of recovery, partnership, and choice. The vision is to create a new mental health system, which will be based on the principles of recovery, partnership, and choice.

The vision is to create a new mental health system, which will be based on the principles of recovery, partnership, and choice. The vision is to create a new mental health system, which will be based on the principles of recovery, partnership, and choice. The vision is to create a new mental health system, which will be based on the principles of recovery, partnership, and choice.

The vision is to create a new mental health system, which will be based on the principles of recovery, partnership, and choice. The vision is to create a new mental health system, which will be based on the principles of recovery, partnership, and choice. The vision is to create a new mental health system, which will be based on the principles of recovery, partnership, and choice.

The vision is to create a new mental health system, which will be based on the principles of recovery, partnership, and choice. The vision is to create a new mental health system, which will be based on the principles of recovery, partnership, and choice. The vision is to create a new mental health system, which will be based on the principles of recovery, partnership, and choice.



Engineering
Library

TC

978

E47

1903

PRACTICAL

FARM DRAINAGE.

126114

WHY, WHEN, AND HOW TO TILE DRAIN.

Chapman
C. G. ELLIOTT,
DRAINAGE ENGINEER.

NEW YORK :
JOHN WILEY & SONS.
LONDON : CHAPMAN & HALL, LIMITED.

1903.

—
COPYRIGHT SECURED.
—

ROBERT DRUMMOND, PRINTER, NEW YORK.


22,111 10-0-55-000-6
Revised 2-2-43 DLA

PREFACE.

THE following pages are presented to those who are interested in the subject of farm drainage. So short has been the time since the introduction of tile drainage in the prairie States, that farmers have scarcely taken time to acquire the requisite knowledge of the subject before they have begun actual operations. The drainage practice of the Eastern States must be adapted to western soil and surroundings. This requires time and close observation. The object of these few pages is to give, in a concise and plain manner, that which the farmer should know, if he contemplates draining his farm. It is not the intention of the author to say all there is to be said upon the subject, but to say enough to give the farmer an elementary knowledge of why, when, where and how to drain his farm. The practical methods described in these pages have been well tested, and are now in constant use by practical men. It is hoped that the language is sufficiently clear to be understood by all.

C. G. ELLIOTT,
Civil Engineer.

TONICA, ILLINOIS,
September, 1882.



CONTENTS.

CHAPTER I.

SOILS AND THE RELATION OF DRAINAGE TO THEM.

Introduction—Kinds of Land Requiring Drainage—Sources of Water—Mechanical Difference Between a Wet and Dry Soil (Illustrated). The Relation of the Contour of the Surface and Subsoil to Drainage—Kinds of Drains—Open Drains—Tile Drains.

CHAPTER II.

ACTION OF DRAINS UPON THE SOIL.

How Tile Drains Affect the Soil—Temperature—Chemical Changes—Drought—Questions to be Considered Before Commencing to Drain.

CHAPTER III.

LEVELING AND LOCATING DRAINS.

The Outlet—Leveling—Level Notes—Leveling Instruments—Location of Drains—Staking and Leveling for Drains—Field Notes of Main Drains—Computing Grade and Depth—Determining and Adjusting Grades.

CHAPTER IV.

DEPTH AND SIZES OF DRAINS.

Silt Basins—Depth and Distance Apart of Drains—Sizes of Tile—Concrete Tile.

CHAPTER V.

PRACTICAL DETAILS OF THE WORK.

Mapping Drains—Grading the Bottom Outlet—Laying Tile—
Difficulties in Constructing Drains—Obstruction of Drains—
Junctions.

CHAPTER VI.

DITCHING MACHINES.

Difficulties Involved—Principles—The Johnson Tile Ditcher—
The Blickensderfer Tile Drain Ditcher.

CHAPTER VII.

COST AND PROFIT.

Cost of Drainage—Cost of Mains—Profits of Drainage.


CHAPTER VIII.

ROAD DRAINAGE.

Improvement of Roads—Surface Drainage—Under-Drainage—
Effect of Tile Drains upon Roads—Care of Drained Roads.

LIST OF ILLUSTRATIONS.

FIG.	PAGE
1. A Dry Soil.....	5
2. A Wet Soil.....	5
3. A Drained Soil.....	5
4. Surface and Subsoil	7
5. Proper Form for Open Ditch.....	10
6. How Tile Drains Affect the Soil.....	14
7. Faulty Outlet.....	24
8. Leveling.....	26
9. Comstock Level.....	29
10. Plan of Drainage.....	32
11. Plan of Drainage.....	33
12. Plan of Drainage.....	35
13. Staking Drains.....	37
14. Silt Basins.....	46
15. Cross-Section of Drains.....	50
16. Map of Drained Field.....	61
17. Tile Hoe	62
18. Grading the Bottom.....	64
19. Outlet	66
20. Junctions	70
21. Johnson Tile Ditcher.....	73
22. Blickensderfer Tile Drain Ditching Machine.....	74
23. Plan for Improving a Road	87
24. Cross-Section of Road Improved.....	88
25. Cross-Section, Showing a Drain for Intercepting Water.	90



CHAPTER I.

SOILS, AND THE RELATION OF DRAINAGE TO THEM.

Introduction—Kinds of Land Requiring Drainage—Sources of Water—Mechanical Difference Between a Wet and a Dry Soil—The Relation of the Contour of the Surface and Sub-Soil to Drainage—Kinds of Drains—Open Drains—Tile Drains.

INTRODUCTION.

But very little attention has been given to land drainage in Illinois and other western states, until recently. A casual glance at our farms in the spring of the year, when many of them are partially submerged, and the farmer, with idle men and teams, is impatiently waiting for the slow natural drainage of flat land, and the evaporation of the rainfall by heat from the sun, before he can begin operations, will convince any observing man that the rapid removal of this surplus water would be of immense benefit to the agricultural community.

The practical feasibility of this work is at present the problem with many. The farmer asks himself and others, "Can I drain my field or my farm thoroughly, and will the probable returns justify the outlay?" Valid and useful conclusions upon this matter can not be arrived at until we have availed ourselves of the experience of others, and have obtained correct ideas of the principles of drainage—what thorough drainage is, and what it will accomplish.

It may be well to mention a few of the benefits accruing from drainage which are of actual money value

to the farmer. These benefits are not hidden away in the soil, but may be seen by any one who will compare a well-drained field with one which is wet and undrained.

First, there is no failure of crops on account of excessive rains. Almost every farmer may put down among his losses the partial or total failure of several acres of land to produce a crop because, during some part of the season, the land was too wet.

Second, the soil is in condition to receive the crop at the proper season of the year, and it begins a healthy growth at once. This will add many dollars to the value of the field each year, and cost no more labor.

Third, the labor which produces a poor crop on undrained land, will produce an excellent one on the same land when properly drained. In this way crops are often doubled on what is called average farm land.

Fourth, by reason of the absence of surplus water in the soil, grain and grass are not "heaved" and frozen out in winter time.

Fifth, whatever fertilizing material is put on the land is made more available for plant food, for the reason that the soil is more porous and not surface-washed, and fertilizers are at once incorporated in the soil. Undecayed matter put upon the soil decays more rapidly and becomes sooner prepared for the use of plants. Fertilizing gases held in the air are carried by the rain into the soil, making it more rich, instead of being washed away or taken with vapor into the air again.

Other advantages will be mentioned as we proceed farther, but these just named will perhaps be sufficient to show the importance of the subject. Each season as it comes, turns another leaf of the book of Farm Economy, telling the same story in different ways, and em-

phasizing it at times in such a manner as to compel the farmer to heed its teachings.

KINDS OF LAND REQUIRING DRAINAGE.

Ponds and sloughs are wholly unfit for cultivation, even in the driest years, without drainage. *Ponds* are basins which seem to have been provided by nature for receptacles of surplus water flowing from the surrounding high land, and are reservoirs for the drainage of land which gives the farmer his profits. These ponds are generally covered with aquatic plants, which are very tenacious of life in wet soil, but easily killed when deprived of their natural nutriment by drainage. *Sloughs* are the natural water-courses of prairie land, being to level land what creeks and rivers are to more rolling and hilly sections. These are often broad and flat, allowing water to spread over rods of valuable land, where by suitable ditches it might be confined to a much narrower space and many acres of valuable land reclaimed.

Flat land under cultivation is usually the first land which directs the farmer's attention to draining. A season which is drier than usual shows to him that such soil, when not too wet, will produce a crop equal to his best fields. On this land the natural drainage is not rapid enough in the spring-time to fit it for the growth of plants. It is generally cultivated when too wet, which causes the soil to become compact and in time of drought it shrinks and cracks, resulting in the ruin of the crop and more than loss of the labor; for the soil is in a worse condition than it was in the spring before the plow was started.

Channels or runs through cultivated land often are common where the land is rolling. Water flows down

the slopes and oozes from the banks until these runs are so wet that they rarely produce a crop, and are a great inconvenience in cultivating.

SOURCES OF WATER.

Primarily the source of all water of use or injury to the agriculturist is the rain-fall. Considered, however, with reference to drainage, we speak of *surface-water*, which rests upon the surface of the soil, a part passing down to the sub-soil, a part flowing over the surface and passing off, and the remainder raised by evaporation or used by plants; *ooze water*, which passes through the soil below its surface and finally rests in some channel or flat land, saturating it until it is unfit for cultivation; *spring water*, which has its source in some one locality of the field, or proceeds from some distant source through its own channels in the sub-soil. These must be provided for by drainage, according to the nature of the case.

MECHANICAL DIFFERENCE BETWEEN A WET AND A DRY SOIL.

If we look at a lump of dry soil by means of a common magnifying glass we see that it is made up of small particles thrown together miscellaneously, having small cavities between them resembling those of a sponge. The particles also have minute pores and cells which hold liquids by the power of absorption. The figures here given are drawn to illustrate this, and are similar in idea to those of Col. Waring, which he borrows from an English Report on Drainage. Let us dry a portion of soil and from it cut a small block. This, placed under a magnifying glass, will appear somewhat as represented in figure 1. It is composed of irregularly shaped particles having channels and cavities between them similar to those existing in a

pile of small stones. These particles in turn have very minute cells, capable of absorbing and holding moisture. In the piece before us there is no moisture between the particles nor in them, both being filled with



Fig. 1 - A dry Soil




Fig. 2 - A wet Soil




Fig. 3 - A drained Soil

air alone. It is evident from the laws of vegetable growth that such soil is unfit for the growth of seed or plant. If we pour water upon this block of dry soil until it will hold no more, we have the state of things shown in figure 2. The cavities, pores, cells, in short, every space before occupied by air is now filled with water. Seeds and roots in such a soil can not thrive,

for all air is excluded, except what little may pass through the water to the growing roots.

If we notice the soil as we put the water upon the block under the glass, we will see that a drop placed upon one side or the top, changes the color of the soil, showing that the soil is moist, but there is no change in the spaces represented in the figure. This state is shown in fig. 3. The minute spaces in the particles are filled with moisture and will hold a certain percentage, varying with the kind of soil, while the spaces between the particles are filled with air. We have here an example of a drained soil in which the plant roots have access to both air and moisture. It will be seen, then, that draining is simply removing the surplus water from the soil. This allows the atmosphere to take its place, thereby giving the plant needed oxygen at its roots, and producing a chemical change in the soil which gives the plants more nourishment.

The amount of water held by absorption varies greatly with the kind of soil. To show that a well drained soil is by no means a dry soil, we have experiments by Professor Schübler, who found that one hundred pounds of dry soil would retain the following weight of water that would not flow off by drainage:

Sand	25 pounds.
Loamy Soil.....	40 pounds.
Clay Loam.....	50 pounds.
Pure Clay.....	70 pounds.

THE RELATION OF THE CONTOUR OF THE SURFACE AND SUB-SOIL TO DRAINAGE.

A cross section of prairie soil usually shows, first, what is known as the soil, which consists of loam, more or less vegetable, to a depth of from 18 to 30 inches, then a few inches of mixed soil and clay, then fine clay,

varying in color according to locality. This constitutes the sub-soil, and in its natural state is not so easily permeated by water.

Natural drainage in such a soil is accomplished by the surface water flowing down the slope, and the ooze water flowing through the soil, most of it passing down to the clay sub-soil, thence gradually oozes down the slope until it finds some place of exit or level. By reference to fig. 4 it will be seen that the relation of surface and sub-soil has much to do with the facility with which artificial drainage is effected.




Fig. 4

At *A* the layer of clay rises nearer the surface than at other places, holding the water back of it until its level becomes high enough to flow over the obstruction, when it oozes down the regular slope and is discharged; or as at *B*, the water after passing through the soil is held below by the clay basin in quantities sufficient to make the soil at *D* unfit for profitable cultivation. Such is the case at *C*. We do not wish it understood that sub-soil clay is impervious to water. It is only comparatively so. The soil is so susceptible to the passage of water that the difference is all the more marked. As seen before, the retentive power of soils varies greatly. Understanding these natural difficulties, we can arrange our drainage with reference to

overcoming them. These things are mentioned, not with the intention of covering all cases, but to suggest to the thinking and investigating agriculturist something of what he should take into consideration when he undertakes to drain wet land.

KINDS OF DRAINS.

Many experiments have been made to find some inexpensive material for, and method of constructing, drains. None have stood the test of time but open ditches for surface drains, and tile pipes for under drains. If the western farmer wishes permanent and effective drainage, he must be at the expense of constructing suitable open ditches for large water-courses, and well laid lines of tile drains for general draining purposes. Drains constructed of boards, brush, gravel, etc., are less effectual and in the long run more expensive.

OPEN DRAINS.

However much open ditches may be disliked, they are often a necessity. The farmer who has experienced the convenience and profit of under-drains conceives the idea of doing away with all open ditches by using tiles and covering them, thus saving all inconvenience occasioned by the ditch, and also adding to his tillable land that occupied as a water-course. This operation will often retard the action of drains which discharge into the large channel, and if the slough is large will wholly prevent good drainage. As noticed before, sloughs on the prairies are the natural water-courses, give surface drainage to large tracts of land either side of them, and during seasons of heavy rain require large capacity in order to remove the water coming to them. In many cases a pipe eleven or twelve inches in di-

RELATION OF DRAINAGE TO SOILS.

ameter would do the work, but these are at present exceedingly expensive and can not often be used by individual farmers because of the expense.

Again, sloughs flowing through tracts of land are flat and require under-draining more than other, themselves have but little grade, so that large pipes would be required to give the water discharge.

If all our land were well under-drained, preventing any accumulation of water in the places in the bordering fields, or surface case under consideration would be removed.

The water, instead of requiring much time as it gathers upon the surface, would be

fast as it gathers upon the surface, and by a soil well drained to a great extent and carried off by the surface.

This drained soil is capable of carrying a great quantity of water before the surface can

carry it off gradually. The surface drain will not be able to carry a great quantity of water at a time.

It is mentioned by the writer, upon the subject of drainage, where drainage is practiced.

practiced. It is a slough.

It must be the area drained, affect at the drainage.

drainage defined as the water.

It is the water.

must be provided, into which all lesser drains may be discharged.

A ditch which is to be a water-course in ordinarily large sloughs, should be of greater dimensions than a cow-path, furrow or spade ditch. A narrow ditch, even if deep enough, will soon wash at the sides, causing sods and earth to fall in. These, with the growth of grass, will soon obstruct the ditch to such a degree that it will be worthless, unless the water flows rapidly enough to wash out all matter, or it is cleaned by hand-work. Besides this it will hold so little water that in every little freshet the land on each side will be flooded and injury done.




Fig. 5.—Proper Form for Open Ditch.

Figure 5 gives the cross-section of a ditch which will stand at the sides and can be easily kept clean. The ditch is twelve feet wide at the top and three feet deep. The sides slope 2 to 1, that is, one-half the width at the top is twice the depth. The earth should be taken 3 feet from the edge of the ditch, and should be smoothed and seeded to grass. A border of 10 feet should remain in grass. This will require two rods of land for the ditch, giving firm land for the banks. Such a ditch can be kept clear of weeds and long grass by mowing with a machine and burning the weeds in the bottom of the ditch. In making the ditch short turns should be avoided as much as possible, as these retard the flow, and occasion washing away on one side

of the ditch at the turn. The grade may be, in almost all cases, uniform with the slope of the surface, as usually the inequalities are very slight in prairie sloughs.

The magnitude and expense of a ditch of this description at first often induces the farmer to substitute some more easily constructed one, and thus cripple his whole system of drainage. After a few years of trial he will have reason to regret his half-way work, and will take measures to correct it. When taken at a dry season of the year, the ditch as above described may be excavated quite rapidly with the help of a road-plow and scraper.

TILE DRAINS.

The good effects of drainage previously mentioned can not be brought about by a system of open drains, only as such a system is constructed for the purpose of affording sufficient outlets for under-drains. In observing the process of natural drainage as shown in fig. 4, we see that such drainage is very slow, since it depends upon the nature of the soil and the relation of the contour of the sub-soil to the surface. Open drains are simply an aid to natural drainage, acting principally upon the upper six or eight inches of soil. Deeper than this, the soil, during the spring-time, is tough and compact, scarcely allowing the plowshare to cut and turn it to the surface, because of its adhesive nature. At the same time, a few inches of the surface soil which has been surface-drained and acted upon by the sun and air, will be friable. Later in the summer, if the season is dry, the lower soil will be found partially dry, but generally it never becomes well drained except at the surface. We must have ditches, but they should be regarded only as necessary accessories to

under-drains, if we wish to realize their full benefit. A tile-drain, in order to accomplish its purpose perfectly, should possess the following requisites:

It should consist of pipes of sufficient size, laid at proper depths, to carry away all water which may come to them.

Each line should have a perfectly free outlet.

The pipes should have sufficient space between them at the ends to permit water to enter.

Each separate line should be laid on an incline, or series of inclines, of regular grade.

The tiles should be of good material and well-burned, in order to be a permanent improvement.

CHAPTER II.

ACTION OF DRAINS UPON THE SOIL.

How Tile Drains Affect the Soil—Temperature—Chemical Change—Drought—Questions to be Considered Before Commencing to Drain.

HOW WATER ENTERS A TILE DRAIN.

A correct understanding of this will help us to determine the best way to make the joints, and also to locate the lines as regards their distance apart. The tiles should have their ends joined as closely as the inequalities arising from moulding and burning will admit of. When this is done there will yet remain sufficient space for the water to pass in or out, but not enough to admit soil, except in the form of very fine silt. At the bottom of the drain and nearly on a level with either side of it, the earth is saturated with water, that is, it can hold no more. The plane forming the upper surface of this saturated earth is called the water-table. Figure 6 shows a cross-section of a drain, the curved line AB representing the water-table, or line of saturation, the darker part of the figure representing the saturated earth, and the lighter portion above the water-table the drained soil. When rain falls upon the surface it descends directly downward by the force of gravity. When all the particles of the drained soil contain all they will hold by absorption, the water passes down until it reaches the saturated soil, when, as it can go no further, it saturates the lower portion of the drained soil, thus causing the water-table to change its place and rise higher. As the water-table rises, the water rises through the joints

of the tiles, and they being inclined, a flow begins and continues until the water-table recedes to the floor of the drain, when the flow ceases. It will be seen that the water-table will vary in height with the quantity of drainage water in the soil. When the water-table rises to the top of the drain, the tile will discharge a stream as large as its caliber. If the water-table rises higher than this, additional head is given and the ve-




Fig. 6

locity of flow is increased, but the depth of drained soil is decreased. The fact that the tiles are porous does not increase the flow nor add to their draining

properties. They would be as suitable for draining purposes if made of glass, or of glazed ware, as when made of porous clay, for they will be taxed to their full capacity by water flowing into the joints. The water-table does not extend on a level indefinitely either side of the drain, but rises as it recedes, the angle of rise varying with the nature of the soil. This fact will be alluded to again in the discussion of the distance apart of the drains.

HOW TILE DRAINS AFFECT THE SOIL.

Depth of Soil.—From what has been said before, it will be seen that the depth of the soil is increased by the action of tile-drains, since, were it not for the presence of the drain, when the water-table rises high, thus decreasing the depth of drained soil, it would remain so until the surplus water was carried off by slow nat-

ural drainage, in place of rapidly, as by the drain. All the soil acted upon by the drain is made similar to that at the surface. Air takes the place of the surplus water, so that a chemical action is begun. The inert soil matter is slowly changed into plant food, making the whole depth of drained soil the natural home for the roots of plants. It is often thought that the roots of farm plants penetrate but a few inches into the soil, and that if the surface is dry, rich and porous to a depth of ten inches, the plants have sufficient room for growth. Professor W. O. Atwater, in the *American Agriculturist*, gives the following on the "Extent and Depth of Roots":

"I have often been interested in noting the ideas most people have as to how far and how deep the roots of plants extend. The majority guess roots of grass and clover penetrate between five and ten inches, and are surprised to find that they reach several feet. I have some roots of timothy, clover, and other plants, dug from a very heavy clay soil, a good quality of brick clay, so compact and hard that a sharp knife, in cutting it, leaves a surface as smooth and shiny as it would cut on the end of a pine board. I have traced the roots of the timothy to a depth of two feet and four inches, and the clover three feet and two inches. A number of years ago a very intelligent German farmer named Schubart, made some very interesting observations upon the roots of plants as they grow in the field. An excavation five or six feet deep or more, was dug in the soil so as to leave a vertical wall. Against this wall a jet of water was played by means of a garden sprinkler; the earth was washed away, and the roots of the plants growing therein laid bare. The roots thus exposed in a field of rye, in one of

beans, and in a bed of garden peas, presented the appearance of a mat or felt of white fibers, extending to a depth of about four feet.

"Roots of wheat sown September 26, and uncovered the 26th of April, had penetrated three and a half feet, and six weeks later about four feet, below the surface. In one case, in a light subsoil, wheat roots were found as deep as seven feet. The roots of the wheat in April constituted forty per cent. of the whole plant. Hon. John Stanton Gould, I believe it is, says that he 'has seen the roots of Indian corn extending seven feet downward,' and Prof. Johnson states that 'the roots of maize, which in a rich and tenacious earth extend but two or three feet, have been traced to a length of ten or even fifteen feet in a light, sandy soil.' Roots of clover, when growing in a rich, mellow soil, extend far, both laterally and vertically. Prof. Stockbridge 'washed out a root of common clover, one year old, growing in the alluvial soil near the Connecticut river, and found that it descended perpendicularly to the depth of eight feet.' Lucern roots are stated to reach a depth of twenty and even thirty feet. Alderman Mechi, in England, tells of a neighbor who 'dug a parsnip, which measured thirteen feet six inches in length, but was unfortunately broken at that depth.'"

It will be seen by this that maximum crops can not be expected until the soil is made light and porous to a sufficient depth to give the plant abundant nourishment. In prairie soil the depth which is so desirable can be obtained in no other way than by under-draining.

Temperature.—A warm soil is another effect of under-draining. When the soil becomes saturated and no means are provided for the removal of the water

except by evaporation, no heat is absorbed by the soil until the water at the surface has been changed to vapor. In the summer the air is very much cooled by a shower of rain, because a certain amount of heat is required from the air and earth to convert a portion of the rainfall into vapor. The same change is necessary when the soil is saturated. If the rainfall is frequent but very little soil is warmed, all the heat of the sun being required to change the water at and near the surface into vapor. If this is true of the surface it is doubly true of soil several inches below the surface, for the water at the surface must be evaporated and the temperature of the soil raised before any warming process can go on in the lower portions of the soil. A drained soil has been found to be from six to ten degrees warmer at seven inches below the surface than an undrained soil at the same depth. This difference in the soil often gives the farmer a season which is from two to four weeks longer, besides giving quick and increased growth to plants.

Chemical Change.—Heat is an important chemical agent. When permitted to enter the soil with air, important changes are made. Vegetable matter, hitherto inert, becomes further decomposed and mingled with mineral matter, thus making the lower soil similar to that at the surface. Again, the ammonia furnished us by the rain is held in a drained soil and aids in this chemical work. In order to see that such changes are made, let a portion of clay or hard-pan be taken from a depth of three or four feet and exposed to the atmosphere. Instead of remaining compact and solid, it will gradually crumble and in time will become chemically changed. The same action goes on

when the earth is in place and the air is allowed to find its way to it, which it can not do until the surplus water is removed.

Drought.—It is often asked “If draining makes a soil dry in a wet year will it not make it too dry in a dry time?” It has already been shown that a drained soil holds a large quantity of moisture by absorption. The soil being very much deepened, the roots of plants have access to the moisture contained in a much larger mass of soil than when undrained. Again, a soil is filled with capillary* tubes, which carry moisture to the surface, where it is quickly converted into vapor. If the surface is mellow and the whole depth of soil loose, the tubes are much larger, so that water is conveyed to the surface in much less quantities. Consequently, less moisture is lost by evaporation. Still further, in dry times the soil below the surface is much cooler than the air, hence, when air containing vapor is brought in contact with it, the vapor is condensed into water and absorbed by the particles of soil. In an undrained soil the surface is made compact by standing water, is baked by the sun when the water is evaporated, is compact below, giving little depth of soil for the plants. Moisture evaporates rapidly through the hard surface, and roots, having a comparatively

* The force called capillary attraction is of great importance to the cultivator of the soil. It is so called from the fact that it is most noticeable in very small tubes, called capillary tubes. It is the attraction which exists between a liquid and a solid when brought into contact. When small tubes are placed in water the liquid rises in them higher than the surface of the water, rising highest in the smallest tube and varying in height inversely as the diameters of the tubes. The soil contains an endless number of capillary tubes which communicate with each other. In hard and compact soils these tubes are much smaller than in loose and mellow ones, and according to the law, moisture is conveyed to the surface, where it is evaporated. If the surface be broken up by any means the capillary tubes are made larger to such an extent that but little moisture is conveyed by them to the surface to be evaporated.

small range, soon feel the ill effects of dry weather. Some soils are naturally very rich and porous, producing good crops when the spring rains are light enough to allow the soil to be worked, but it has been found that such soil produces much larger crops even in dry times when well drained. In short, thorough under-draining has been found to be a most efficient preventive of drought. It also makes better tillage possible, which in itself is a great advantage, and it makes all parts of the soil available for the use of useful crops.

QUESTIONS TO BE CONSIDERED BEFORE COMMENCING TO DRAIN.

There are many farmers who have poor crops and consequently find very little profit in farming, not because their land suffers from an excess of water in the soil, but by reason of poor management and poorer tillage of a soil which is naturally well drained. It is a weakness, particularly prevalent among western farmers, to put a little work on a great deal of land. The farmer should understand the value of labor upon the soil before he invests much capital in under-drainage. If the land which he has been cultivating has become filled with seeds of noxious plants until the crops consist of half grain and half weeds, let him turn his attention and capital to more thorough cultivation as the first thing to be done in order to make agriculture profitable. If his soil has become "furrow-trod" and produces a sickly crop, let him rotate his crops, plow in the fall, seed to grass and pasture until, by the best means known to agriculturists, the results of his labor show that he has succeeded. He may cheat the soil for a time by poor cultivation, but at last the farmer will suffer the full penalty for his treatment of his most profitable friend.

The first question that a farmer should consider before undertaking drainage, is this: Is my land, which is naturally drained, receiving such treatment at my hands as to give me maximum crops? Draining is expensive, and in order to obtain profitable returns from the outlay he must cultivate in such a way that the soil will bring him the largest possible crops. The more money there is invested in the land the greater necessity there is for making sure of a corresponding return. The gardener who is to pay two hundred or three hundred dollars an acre for land near some city which will afford him a good market for his products, should carefully take into account whether the crops which he intends to raise, the amount of which will depend upon his own skill, capital and adaptation of the soil, and the prices he can get for them, will justify the purchase. He very well knows that with poor crops as his only source of revenue he would soon be lost in a hopeless labyrinth of debt. It is much the same with the farmer in draining. A careful, industrious farmer can drain his land and realize a handsome return from the investment. A slovenly man, who will not cultivate well the land which nature has enriched and drained for him, need not expect to make draining pay.

Again, fashion rules the farmer to an extent which he is often unwilling to admit. A new implement has its run in a neighborhood as surely as a new pattern of goods among ladies of society. If one man builds a convenient and showy barn many of his neighbors will speedily follow suit, regardless of their means and needs. If neighbor A drains a field and thereby increases his crops, neighbor B, seeing that he has suc-

ceeded well, will forthwith begin draining one of his fields. This habit of imitation is not to be discouraged, for it is an important incentive to advancement in all things. A good example is worthy of imitation. But in the last case mentioned neighbor A may have given the matter careful thought, and have laid his plans with so much foresight, and carried them out with such thoroughness, that the results are highly satisfactory, while B, seeing only the results, hastens to obtain similar ones without the preparatory care. He, perhaps, does his work at random, and finds the profits much smaller than he was led to suppose. Each man should make the case his own. In connection with what his neighbor has done he should study his own soil and the natural facilities he has for thorough work.

Another matter to be seriously thought of is the expense. Draining, if done thoroughly, is expensive at the outset. Of course a small drain here and there on the farm does not involve much outlay. But prairie farms are usually wet to such an extent that outlets must be provided at considerable expense, which, in themselves, give no adequate return, and often an entire system of mains and sub-mains must be laid before much profit can be directly obtained. A survey should be made, giving the elevation and distances of different portions of the farm or field. From this an approximate estimate of the cost of a drain or system of drains can be made. However much or little is done the farmer should be prepared with the requisite knowledge and money to begin at the right place and do thorough work as far as he goes. It must be remembered that under-draining is not like building a fence,

which may be moved if it is not in the right place, or which in a few years will rot down and require rebuilding, but it is a work which, if well done, will benefit the farm for future generations as well as the present.

CHAPTER III.

LEVELING AND LOCATING DRAINS.

The Outlet—Leveling—Level Notes—Leveling Instruments—Location of Drains—Staking and Leveling for Drains—Field Notes of Main Drain—Computing Grade and Depth—Determining and Adjusting Grades.

THE OUTLET.

The first and most important consideration in good drainage is the outlet. We may use tiles as large or as small as we please, and lay them as accurately as a railroad is graded, and even go to the expense of locating the lines ten feet apart, and yet if the outlet is not free, the drainage will not be successful in all respects. The lack of good natural outlets is perhaps the greatest difficulty that the western farmers have to surmount in draining flat prairie. To make underdraining successful, he must often deepen the water-course by making open ditches, even larger and deeper than the one previously described. In order that a tile drain may discharge all the water that it is capable of carrying, the water must flow away with perfect freedom.

It is thought by many that some contrivance may be used by which the force of gravity may be circumvented, and the drain made to discharge its water, notwithstanding a faulty outlet. A box or barrel is sunk at the lower end of the drain, and the water made to rise twenty or thirty inches and then flow away through a shallow open ditch. The effect of this is shown in

fig. 7. We must remember that if water will enter at the joints of the drain, it will flow out into the soil just as readily if the stream in the tile is retarded or entirely stopped. The water, as shown in the figure, flows through the drain to its outlet A, where, being held by the sides of the pit or box, the water must rise to the level Bb before it can flow off. The soil above the drain becomes saturated up to the line Bb, thus leaving a portion of land near the outlet undrained, or only partially drained, according to the




Fig. 7 - Faulty Outlet

relation between the height to which the water must rise and the grade upon which the drain is laid. Nor is this a small waste of land, especially where the grade of the drain is slight. We will suppose that the mouth of the drain is three feet below the surface, that the water must rise twenty-four inches before it can flow off, and that the grade of the drain is four inches in one hundred feet. The drain will now back water for six hundred feet, and will greatly injure the land for a distance of three hundred feet above the outlet. When the grade of the drain is great near the outlet, the damage is not so serious. When the soil above the drain becomes saturated from any cause, as in the case of an obstructed outlet, the combined weight of

soil and water above the drain causes the tile to act like a continuous iron pipe, the head of water above forcing the water through the pipe to a proportionate height at the outlet. This, however, is not drainage. The drain must have a free outlet, and the tiles should never be quite full in order to give perfect drainage to all of the soil through which the drain runs. The proper construction of the outlet will be taken up under the subject "Location and Construction of Drains."

LEVELING.

Unless inaccurate and in the end costly guess-work is depended upon in draining, we must use some accurate method of obtaining the difference of elevation of various points on the farm or field upon which we wish to operate. Leveling can be done in various ways, but in whatever way it is done the principle remains the same. We first secure a horizontal line of sight, and, having a rod graduated to feet and fractions of a foot, we hold the rod upon the point whose elevation we wish to determine, and find at what mark the horizontal line intersects the rod. This is called a rod-reading. The rod is then moved to another point and a reading is again taken. The difference of the readings is the difference of elevation of the two points upon which the rod was placed. If we wish to take a system of levels, that is, find how much higher or lower different points are than the starting point, the process becomes more complicated, for the reason that the instrument must be moved and the levels all referred to the same datum. The following method of operating and keeping the notes is general, and will apply to whatever kind of instrument is used to obtain the horizontal line.

For convenience in leveling for drainage purposes, we begin at the place which we consider the lowest point upon the farm or field, and make a preliminary level survey in order to find the elevation of the lowest




Fig. 8. - Leveling

portions of land requiring drainage, and the distance of such places from the common outlet. We assume the starting or outlet point at the surface of the ground to be 100 feet above an imaginary plane below called the *datum plane* or *datum*. Place the instrument at some convenient distance from this point (the distance will depend upon the power and accuracy of the instrument), take a reading at the point A, Fig. 8, which we will assume for illustration to be four feet; add this to the assumed elevation of A, and we have 104 feet, which is the height of the line of sight or of the instrument above *da-*

tum. Now take the rod to B and take a reading which we will assume to be two feet. Subtract this reading from the height of the instrument and we have 102 as the elevation of the point B. Change the instrument to some place beyond B, as at C. Take another reading at B, called a backsight, or commonly a plus sight, which we will suppose is

1.5 feet. Add this to the elevation of B for the height of the instrument in its new position, which is 103.5 feet. Take a reading at C, which is one foot. Let these operations be repeated until the elevation of all points desired is found. Observe that at every change of the instrument a back-sight must always be taken upon the last point at which a reading was taken, and its reading added to the elevation of that point for a new height of the instrument. Also subtract every fore-sight reading from the height of the instrument, to obtain the elevation of that point. The notes should be kept as indicated below:

LEVEL NOTES.

Stations.	Distance.	Back-sight or sight.	Height of instrument.	Fore-sight or sight.	Eleva- tion.
A.....		4.00	104.00		100.00
B.....	400 ft.	1.50	103.50	2.00	102.00
C.....	500 ft.	3.00	105.50	1.00	102.50
D.....	525 ft.	3.00	107.50	1.00	104.50
E.....	375 ft.			0.90	106.60

NOTE.—The *datum* height 100 is used to avoid minus quantities. If the elevation of some point should be 98, it would indicate that such a point is two feet lower than the starting point.

The distance between the points should be measured and recorded in the notes. A rude sketch of the lines and stations may be made. From this preliminary survey the farmer can ascertain what fall he has in given distances, and how he had best lay out his drains. In short, he can tell what it is possible for him to do.

LEVELING INSTRUMENTS.

There are many kinds of leveling instruments within reach of the farmer. Perhaps the ordinary water level is as easily made and as efficient as any. This may be made in the following manner: Get the tinner to make

a tin tube one inch in diameter and four feet long, turned up at the ends two or three inches, as shown in fig. 9. Insert in either end phials one-half inch in diameter, and long enough to allow about two inches above the tin, having previously knocked out the bottoms, that there may be free communication between them. The phials may be fastened in place by plaster of paris. Clamp the tube securely to a block of wood and place it upon a tripod, so that it may turn readily upon a pivot. The legs of the tripod may be hinged upon the head. This will add to its convenience. To use it, pour water in the tube until it is nearly filled, and adjust the tube so that the water may be easily seen in the glasses. The water having been previously colored by carmine, the height of water in the two phials will form a level or horizontal line. The eye should be placed at a distance of three feet from the tube, and raised or lowered until the line of sight prolonged will coincide with the height of the water in the tubes. An assistant should move the target upon the rod until a signal from the one at the level indicates that the target marks the intersection of the level line with the rod. A good eye-sighting along this line can, with considerable care, obtain very good results. This is a slow method for long distances, for the eye can not prolong the line indicated by the water in the phials to any great distance. When the level is to be moved, the phials may be corked until it is nearly adjusted again, when the corks should be removed.

A carpenter's level having sights upon it, and made to turn upon a pivot on a tripod, is another kind of level with which fair work may be done. Whenever a spirit level is used, it should be examined to see if it

is in adjustment. If not, correct work can not be expected to be done. The advantage which the water level has, over the spirit level is that the water always indicates a horizontal line, while the spirit level may be out of adjustment to such a degree as to be unreliable. The sights put upon the spirit level require accurate construction, or they will not give correct results. Either level accurately constructed is reliable in itself, but it will be seen that the former is more easily made so than the latter. Whichever instrument



THE COMSTOCK LEVEL.

is used, no little care is required on the part of the beginner if he wishes correct work. He should first see how correctly his instrument will work, by finding the elevation of the same point from different positions of his instrument. If the results disagree to any extent, he should try to find whether the error is in his work or in his instrument.

It is often the case that the water level is not expeditious enough in its work, and the engineer's level is too complicated and high-priced for the farmer. To meet this want the Comstock Level, shown in the above figure, seems well adapted. It is manufactured by

William T. Comstock, 23 Warren St., New York. The instrument is made of brass, lacquered so that it will not tarnish. It consists of a sighting tube A A, fourteen inches long, having a pin-hole through one end, through which to sight, and adjustable cross-wires at the other. The tube is mounted upon Ys Y Y', and can be taken out and reversed upon them for adjustment. The Ys are mounted upon a circle, which moves within another circle, as shown at C C'. The inner circle contains the level bulb, which can also be adjusted by a small screw beneath the plate. One quadrant of the outer circle is graduated to single degrees, and the inner one marked at intervals of 45° , so that it may be used in laying off angles for buildings and other similar work. The instrument is leveled up by means of the thumb-screws S S, which rest upon the tripod-head B. A plumb-bob with its line passing through the center of the instrument, permits its center to be set over any desired point. The instrument mounted and in adjustment is thus made very convenient and well adapted to the purpose for which it is made. The level can be turned to any point of the compass, and its parts are all arranged for adjustment.

The engineer's spirit-level is the most accurate instrument, and the one with which the most rapid work can be done. The farmer, by giving considerable study to the subject of leveling, and using a great deal of care, with common instruments can do work that will be sufficiently accurate for ordinary farm drainage, but he will find it, as a general thing, to be a matter of economy to employ a surveyor with accurate instruments, whose experience and reputation in their use will be a guarantee for correct results.

LOCATION OF DRAINS.

Mains.—Having found the difference of elevation of various portions of the land to be drained, we are prepared to fix upon the lines for the main drains. This is a work which, in many places, gives opportunity for the exercise of much skill in the use of knowledge pertaining to drainage. It will be assumed that sufficient level-notes have been taken, and distances measured, to determine the fall per 100 feet between the particular spot to be drained and its nearest outlet, or, if the land is nearly flat, the amount of slope it has in any direction.

The first knowledge that the farmer should avail himself of is, that which he can obtain by observation in the spring of the year, when the soil is saturated with water. At such times water will be found standing above the surface in hollows or basins in the land, and also on flats which seem as high as the surrounding surface. Mark these places and determine, if possible, whether the water is held by a clay sub-soil, as shown in fig. 4, or by the quantity of water retained in the soil at lower portions of the field. In the first case the natural drainage will be very slow, even though the elevation be sufficient; while in the latter, the natural drainage will go on rapidly if the surplus water is removed from the lower portions of the field, thereby giving the water an outlet through the soil. If the whole field seems nearly flat, see if there are not some spots which are wetter than others, though the contour of the surface does not indicate it. Upon examination it may be found that the cause of this is with the sub-soil, as before noticed, or with the soil itself, it being made up largely of clay and more retentive of water.

The bearing of these observations on the location of mains is this: There are places, such as have been mentioned, which must be drained by a system of




Fig:10

branch drains. The nearer the mains can be brought to these the less will be the expense of the branches and the more effectual will be their action. By these observations the farmer has an accurate method of finding the lowest places through which all main lines of drains should pass. The variation in the course of the main to suit particular

cases is often precluded by the slope of the surface, and also by the extra expense a longer main would incur.

The general rule for the location of mains is to let them follow the lowest land, or course of natural drainage. The surface then slopes towards the drain, making both natural and artificial drainage easy. We might say here that in all cases we should try and take every advantage that nature has given us in this work, for artificial drainage is only completing the work which nature has begun.

There are cases which require us to make exceptions to the general rule just given. First, the drain should be as free from angles and short turns as possible. In other words, it should be laid on a straight line, or a series of straight lines, connected by long curves. A few words in explanation of the advantage of straight lines and easy curves will convince the reader of their importance. There is a certain number of feet or inches

of fall that can be used in a given distance. The shorter we can make that distance by cutting across angles the greater the fall per 100 feet we can get, and consequent greater velocity of flow and discharge of the drain. When the total fall is slight, as is very often the case on land which suffers most severely for want of drainage, every thing that can be done to increase the velocity of flow is of prime importance.




Fig. 11

Again, mains must be made of larger tiles than any other of the lines, and so cost much more per foot. Crooks in the line increase its length and consequent expense.

Short curves decrease the velocity of flow, so that, if we wish to have a uniform velocity in all parts of the drain, the grade must be increased at the bend, and as a consequence, the grade of the entire line must be lessened.

It will be seen that there are many things peculiar to each location to be considered in determining the

proper course for mains. In making the line shorter in order to lessen the expense and increase the fall, we may by a deep cut, made to avoid some turn, increase the cost more than all we save, or by so doing we may fail to drain some land through which the drain should pass.

It is only by carefully weighing all those things which enter into the expense and efficiency of the work that the farmer or drainage engineer can arrive at the most desirable plan.

It must always be borne in mind that in small ponds, drained by a single line of tile, the drain should pass entirely through the pond, and thence to the outlet, instead of beginning at the edge of the pond as in the case of an open ditch. The reason for this is evident when we remember that water from the land on either side of the drain enters it through the joints of the tile, while the land at the end of the drain is drained but very little.

Sub-mains and Branches.—It is often the case that a single line of tiles laid through a flat, basin or hollow will afford a sufficient drainage for the purpose of the farmer. When we wish for the thorough drainage of flats, ponds or swamps, we must have mains to give an outlet for the water when collected, and a system of sub-mains and branches to collect the water from the soil and discharge it into the mains. There are different systems of laying out branches, the value of each depending upon the area to be drained.

Figure 10 shows a system commonly used, but as a general thing it is not to be commended. It consists of parallel branch drains discharging into the main, often at right angles to it. If the main is of proper size it will of itself drain the soil for a distance of from

forty to fifty feet on either side. It will be seen that the portion of the branches between the lines a b and c d are then superfluous, the main alone being sufficient to drain that amount of land.

A better system for large areas is shown in fig. 11. Parallel sub-mains discharge into a silt basin, and branches parallel to these discharged into the sub-mains with but little waste of drains, each drain acting upon its own area of soil.




Fig. 12

In fig. 12 is shown an adaptation of both systems to suit the land. Upon the right is a narrow piece of flat land, extending some distance from the main, which can be drained most economically by two parallel branches running at a proper angle to the main. At the left of the main is a flat extending lengthways of the main, but wider than can be drained by it, hence a small branch is laid out parallel to the main.

These examples are, perhaps, sufficient to show the way in which branch drains are to be adapted to accomplish the work desired. Their distance apart and depth will be treated of under their appropriate heads. The junction of all branch drains with mains and

sub-mains should be at such an angle that the pipe will discharge as nearly as possible in the direction of the current of the main and larger stream. Where it is necessary to have the drains connect at right or obtuse angles, the junction tiles should be curved in the direction of the current into which it discharges. It will be observed that in the figures given all angles are avoided. When a change of direction is desired curves are used. The reasons for this will be discussed more fully further on.

We wish to urge upon all who are about to undertake drainage that the application of correct principles to practice is what is most needed. We can not always fully carry out a correct theory in practice, but the nearer we come to it the better will be our work.


STAKING AND LEVELING FOR DRAINS.

The next step is to lay out the drains and properly prepare them for their actual construction. This should not be done by guess work, either by the farmer or professional ditcher. Draining on prairie land is a very different thing from draining on hillsides, or near the bank of some lake or creek. We can not afford to waste time, money and strength trying experiments in draining, when the success of the work may be known before the ditch is begun or a single tile laid. There are several methods of preparing the drains for the ditcher, and it is probable that the one that is best understood by the operator will seem to him the most desirable. The method we shall describe we think has the advantage of being applicable to every case, and easy to work from in constructing the drain.

We shall attempt such a minute description of it that any one, whether he possesses an engineer's level,

water level, or any other means of obtaining a horizontal line, can stake out and level the drains.

In all the operations of staking out, leveling, grading and laying drains, we begin at the outlet. This is the base upon which to found our calculations. Having previously determined the position of the outlet, and the course of the drains, from observations made in the early spring, and the preliminary levels before mentioned, we prepare stakes of two kinds with which to stake out the lines. One of these is called a *grade peg*, and should be about one inch square in section, and eight inches long. The other is called a *guide stake*, and is best when made of boards one inch thick, two inches wide and two feet long. The upper four inches of this stake should be planed on one side sufficiently smooth to receive and hold a pencil mark. An idea of these stakes and their use may be obtained from fig. 13. Knowing about the length of drain to be laid out, prepare a set, which consists of a grade peg and guide stake for each fifty feet of length. We also need a measuring chain or a tape line graduated to feet, and a hatchet with which to drive the stakes.



Begin at the outlet of the main and drive a grade peg about one foot to the right of the center line of the drain, and as near the end as is desirable. At the right of the peg and about five inches from it, set a guide stake, near the top of which mark O with a heavy lead pencil (see figure). Measure a length of fifty feet from the O stake and set a grade peg and accompanying guide stake, as in the first case, and mark the figure 50 upon the guide stake. The upper marks upon the guides indicate the number of feet of length from the outlet. The grade pegs should be placed as near to the edge of the proposed ditch as they can and remain firm after the ditch is dug. There is no reason why the stakes should be set fifty feet apart rather than any other distance, except that in practice it seems to be the most convenient to work from. Let the whole main line be staked out in this manner, numbering the stakes O 50, 100, 150, etc. Where there is a curve in the ditch let the chain or tape follow the line, that we may know the exact number of tiles required.

Another thing to be noticed at the time the main is staked out is, where the sub-mains and branches enter. Wherever a junction is made a grade peg and guide should be placed. This peg marks the outlet of another drain, and should be marked O, and its name in addition to its number, on the main line. An example of this may be seen at stake 150 in fig. 13.

Some system of designating drains is needed where there are many, in order that the notes may be kept without confusion, and correspond with the plat which is made after the drains are staked out. The main is known simply as the main. A sub-main is a prominent branch of the main, which has branches of its own. We call the sub-mains branch A, branch B, etc.,

in order as they are laid out, counting from the outlet of the main. Branches of the sub-mains are designated as No. 1, 2, etc., of A ; No. 1, 2, etc., of B ; and so on, numbering in order from the junction of the sub-main with the main. The guide stakes on each branch are numbered from its junction towards its source.

Having staked out our lines, we next take our leveling instrument, however simple it may be, and find the elevation of each peg by setting the level rod on the peg, which should be driven down even with the surface, and taking a reading in the manner described under the head of leveling. The pegs being driven to the surface of the ground, their elevation above the *datum* plane will truly represent the surface of the ground along the line of the drain. Call the elevation of the peg at the outlet 100 feet. Take another level where the outlet tile will be placed (see *a*, fig. 13), and be sure that there is sufficient fall below it to carry away the water as fast as it is discharged. This last level will give the elevation of the bottom of the tile at the outlet, or what we call the grade line at O stake.

The method of leveling and keeping the notes is the same as previously described, except that it is more complete. There are added to the notes before described, three columns for computing the grades and depth. The following is given merely as an example to show the method of keeping the notes. Figure 13 gives a section for the purpose of showing how the stakes are set and marked, both for depth of ditch and length of line, but it is not a true profile from the notes here given. This will be referred to again.

FIELD NOTES OF MAIN DRAIN.

Sta.	+S.	H. of l.	-S.	Eleva- tion.	Grade Line.	D'pth	Dep. in ft. & in.	Remarks.
O	645	106.45		100.00	97.25	2.75	2-9	Grade 50 to 100, or 6 inches to 100 feet. A as low as outlet tile can be laid.
A			9.20	97.25				
50			6.32	100.18	97.50	2.63	2-7 $\frac{1}{2}$	
100			5.92	100.53	97.75	2.78	2-9 $\frac{1}{2}$	
150			5.61	100.84	98.00	2.84	2-10 $\frac{1}{2}$	
200			5.12	101.33	98.25	3.08	3-1	
250	7.10	108.94	4.61	101.84	98.50	3.34	3-4 $\frac{1}{2}$	
Br. A								Branch A enters at 300. *Change grade to 32 -100, or 7 $\frac{1}{2}$ inches to 100 feet.
300			6.72	102.22	98.75	3.47	3-5 $\frac{1}{2}$	
*					*			
350			6.11	102.83	98.91	3.92	3-11 $\frac{1}{2}$	
400			6.72	102.22	99.07	3.15	3-17 $\frac{1}{2}$	
450			7.21	101.73	99.23	2.50	2-6	
500			7.11	101.83	99.39	2.44	2-5 $\frac{1}{2}$	

Each drain has a set of notes similar to the above. The notes for branch A would be headed branch A from stake 300 of main. A branch of A would be headed No. 1 from 225 of A. By this system of notes everything pertaining to the survey is kept distinct, and may be referred to at any time. We will next take up the method of computing grade and finding the depth.

COMPUTING GRADE AND DEPTH.

It will be noticed that in the "Field Notes" given, there are three columns of figures more than were given under the head of "Leveling." The first of these is headed "Grade Line," so called because it contains the elevation above *datum* of points on the line upon which it is proposed to lay the drain. These points are below and opposite every "grade peg"

whose elevation has been found and recorded in the column of "Elevations." When connected by a line they form the "Grade Line," or line which determines the position of the drain with respect to its depth.

The second additional column, headed "Depth of Cut," or simply "Depth," gives the distances from the grade pegs to the grade line, or the depth of cut to be made, measured from the pegs. The numbers in this column are feet and decimals of a foot, as these are much simpler for computation. The last column of the three is the same as the preceding one, except that the numbers are feet and inches in place of feet and decimals of a foot. This change from decimals of a foot to inches is for convenience in digging the ditch, as the common measuring square is the most convenient and most commonly used in laying off a measuring gauge. If the leveling rod used in the work is graduated to feet and inches, only one column will be necessary, as the depth will be given in the same units. Using the scale of feet and inches, however, makes the computations much more difficult than they are when the decimal scale is used. The column headed "Remarks" contains comments upon the grade, location, etc., which are often a very valuable part of the notes.

We have briefly explained what these columns contain. We will now notice the method by which they are obtained. The starting point of the grade line was ascertained when we found the place for the outlet of the drain, shown at *a* fig. 13, and recorded in the notes as 97.25. We have found by previous leveling that there is sufficient fall below to allow the water to flow away freely, if we locate the outlet of the line at this point. Now, ascertain by the notes the fall we have in the given distance (the principles in-

volved in this will be discussed hereafter), and divide this by the number of hundred feet, and we have the grade, or fall per 100 feet. Suppose that this, as given in the first of the notes before referred to, is .50 foot, or .25 for each 50 feet of length. Add .25 to 97.25, and this will give us the grade line elevation at stake 50, or 97.50; then to this result again add .25, and we have the grade line elevation at stake 100, or 97.75, and so on—continuing to add .25 to each grade line elevation to obtain the succeeding one, until, perhaps, it becomes necessary to change the grade, when the new grade, or fall per 50 feet (which in the notes given is .16), is substituted for the .25 in the successive additions, and the process continues as before.

To obtain the next column, subtract each grade line elevation from the elevation of the peg at the same station, or subtract each number in the grade line column from the corresponding number on the same horizontal line in the elevation column. The result will be the depth of ditch to be dug at each peg. Thus, by subtracting 97.50 the grade line elevation at station 50 from 100.13, the elevation of the grade peg at the same station, we have 2.63 as the depth of the cut. The decimals in this column are then changed to inches, and the depth in feet and inches written, for convenience, in a separate column, thus 2.63 feet becomes in the next column 2 feet 7 $\frac{5}{8}$ inches. The numbers in this column headed "Depth in Feet and Inches" are now marked upon the stakes at the respective stations, as shown in fig. 13. The stakes now show two sets of numbers. The upper one indicates the distance from the outlet; the lower one shows the depth at which the tiles should be laid, measuring from the top of the grade peg. This is the mechanical oper-

tion of computing grades, and we trust that sufficient explanation has been given to make the methods plain. There are, however, important principles which should govern this work in order to insure economical results.

DETERMINING AND ADJUSTING GRADES.

We will suppose that the desired drains have been staked out and leveled, and we have all of the necessary leveling notes in our book. Determining grades requires much skill if it is done rapidly and in the best manner. It at least requires careful thought, and the inexperienced will find that a profile made from the notes will greatly aid in the work.

The question of how little grade a drain may have and work successfully may be answered by asking, How accurately will the drain be laid? We know of drains laid on a grade of one inch to 100 feet. Such drains must be laid with the greatest possible precision, or they will fail. Drains laid on a grade of two and three inches have proved eminently satisfactory when the work has been well done. Were it possible to avoid it, we should never lay a drain on a less grade than two inches in 100 feet. But there are many places, where, if we drain at all, under the present system of things, we must lay drains upon a less grade, and when it is necessary to do so, too much pains can not be taken in finding a correct grade, and laying the tile with precision.

Entering more into the details of deciding upon grades, for the sake of giving a clear idea of every step, we will suppose that the outlet of the drain is to be 3 feet deep, and the length of the drain 700 feet. By subtracting the elevation at the outlet from the elevation at the source, as found in the notes, we find

that there is a fall of 28 inches in that distance. Dividing the number of inches of fall by the number of hundred feet, we have 4 inches as the grade per 100 feet. If the drain is run on this grade it will then be as deep at the upper end as at the outlet. If we wish to have the drain 3 feet deep at the outlet, and only 2 feet 5 inches deep at the upper end, we shall have 7 inches more fall, which will be available to use in the grade of the drain, making a fall of 35 inches, or 5 inches per 100 feet. Again, supposing we wish to have the outlet only 2 feet deep, and the upper end 3 feet deep, the fall which can be used in the grade of the drain will then be decreased 12 inches, which leaves us only 16 inches total fall, or $2\frac{2}{3}$ inches per 100 feet. Again, taking the same example, we have the same total fall in the whole distance, but there is a rise of ground somewhere between the outlet and the upper end, as may be seen in fig. 13, through which, if the drain were laid on a uniform grade, as noticed in the first examples, much deep digging would be required, which may be avoided by using two or more grades. For example, let us lay out the first 300 feet from the outlet on a grade of 6 inches per 100 feet. We have now used 18 inches of the fall, and if we wish the drain to be the same depth at the source as at the outlet, we have only 10 inches fall left for the remaining 400 feet, or $2\frac{1}{2}$ inches per 100 feet. This gives a grade that may be relied upon to do good work, and will not be as expensive to construct. It is often the case that there is not sufficient fall to permit the use of two or more grades on the same line; in such cases the deep cut can not be avoided.

We might go on multiplying examples, but those already explained may be sufficient to show the way

any practicable system of grades may be made out. Each new field upon which drainage is undertaken will present examples peculiar to itself, which will afford abundant opportunity for the exercise of skill on the part of the farmer or engineer.

It is desirable that the grade of the drain increase toward the outlet, rather than the opposite, though this can not always be done. When a branch enters another drain, it is best to have an outfall of an inch or two, in addition to the grade of the drain. This overcomes the resistance offered by the bend at the junction. If the grade is very slight, it is not best to sacrifice any of it in this way, but let the branch enter on the regular grade. At every bend in the line the additional friction causes a decrease in the velocity of the flow, and it is best to increase the grade at that point, especially if the bend is somewhat short.

These few suggestions may be enough to enable any one to adapt his work to the case in hand. The depth of drains, which will be considered soon, will often have much to do with determining grades. No absolute rule can be given ; but uniformity should, as much as possible, be aimed at. Carelessly laid out grades are a fruitful source of trouble with drains. If the water alternately flows rapidly, and then almost stands still, the tile is at one place full, and at another only part full. It will be seen that the tile will discharge only part of what it is capable of doing and would do if it were laid on a carefully arranged grade. A careful survey and corresponding grade will often add one-half to the efficiency of the drain.

CHAPTER IV.

DEPTH AND SIZE OF DRAINS.

Silt Basins—Depth and Distance Apart of Drains—Sizes of Tile—
Kind of Tile—Concrete Tile.

SILT BASINS.

The silt basin is often a valuable auxiliary to a system of drains, but it is not used as much as it would




Fig. 14 - Silt Basin

be if its advantages were better understood. It may be described as a small well, placed either in the line of a single drain, or at the junction of several drains, and serves several different purposes. Figure 14 gives an idea of the construction and use of the silt basin. It may be built of brick, stone, or plank, and may vary in diameter from twelve to twenty-four inches, according to the use for which it is intended. There should be a depth of twelve inches below the tile for

the deposit of muddy matter. In the figure given it is shown two feet in diameter, constructed of brick, with a stone foundation. In draining it is often desirable that several sub-mains or branches should join at one place, and there unite in one line as an outlet to the whole system. This is the use of the basin, as shown in the figure here given. It permits us to unite several drains entering at different angles, without the objectionable feature of short turns, which we have before noticed. To facilitate the action of the drains, the outlet of the basin should be a few inches lower than the outlets of the lines of tile entering it.

Another advantage is, that the fine earth, or "silt," as it is called, which finds its way into the tile and is carried along with the drainage water, is permitted to settle in the basin, instead of being carried on by the current, to lodge in some portion of the drain where a turn is made, or where the velocity is decreased by a less grade. The basin should have a cover, which may be removed and the silt taken out before it impedes the flow of water through the tiles.

Another use of the silt basin is to prevent the silt from obstructing the drain in cases where the grade suddenly changes from a steep grade to one considerably less. This retards the flow, which causes the silt coming from the upper part of the drain to be deposited at the point where the change to a less grade is made. Here is where the basin should be placed, in order that the silt may be intercepted and removed when the lower portion of the basin becomes full. For this purpose the diameter of the basin may be much less than for the purpose of collecting the water of several drains.

In the ordinary drainage upon western farms, there

is but little necessity for the construction of basins for the purpose of simply collecting silt, for there is usually not enough difference in the grade to cause any alarm on that account. Yet near streams which break the land up into alternate steep slopes and flat bottoms, they are sometimes a necessity. In long mains, however, it is best to locate silt basins at various places along the line for the purpose of watching the action of the drain, and to see that its several sections are in perfect condition.

Where the soil consists of loam on a firm clay sub-soil, there is very little and sometimes no deposit of silt after the drain has been in operation a few weeks. There are many sub-soils, even in prairie lands, which contain streaks of sandy material, which, for some time after the construction of the drain, will find its way into the tiles. It will be seen that the provisions made for the interception of silt must be regulated by the kind of material in the soil through which the drain runs.

We can not urge too strongly the use of the silt basin for the purpose of collecting the water of several drains into one, and thence conveying it to the ultimate outlet. In the system of laying out drains, described in a former paper, and shown in fig. 11, the use and importance of the silt basin is shown. A judicious use of the silt basin for the several purposes for which it is intended, will greatly increase the efficiency of any system of drains.

DEPTH AND DISTANCE APART OF DRAINS.

Depth.—So intimately are the subjects of depth of drains and their distance apart connected, that we can not fix upon one without taking into account the other.

The first question which should be answered is in reference to the depth which we wish to drain the soil. What is the most suitable depth for the soil we have, and the purpose for which it is to be drained, taking into account the cost of drains at different depths, and the comparative advantages to be derived from them? The drains must at least be placed deep enough to receive no injury from frost during the winter. This is about two feet, though drains much nearer the surface than this have done good work for some time, but can not be regarded as safe. How much deeper than this we had better go depends upon several facts and principles, to which we hope the reader will give attention, for in this, as in many other matters of drainage, no absolute rule can be laid down and mechanically obeyed.

Many farmers have a mistaken idea in thinking that the removal of surface water sufficiently to fit the soil for plowing in the spring, and comfortable tillage during the summer, is the sole object of drainage. The advantages of a deep soil, and the use made of it by growing crops, have been explained in previous chapters. If we wish a deep soil, it is evident we must remove the surplus water and admit the air to the depth to which we desire the roots of the plants to penetrate and receive nourishment. We hear many arguments in favor of very shallow cultivation of growing crops, on the ground that the roots at the surface will be cut in pieces and so deprive the plant of nourishment. This argument will apply only to undrained or shallow drained land, where it will be found that the great bulk of the roots lie near the surface, only a few penetrating the undrained soil.

In order to obtain a given depth of drained soil, let us notice a few things connected with the action of drains which were merely hinted at in the explanation of fig. 6. In fig. 15, we have a section of three drains T T T. It was stated under this heading, "How Wa-




Fig. 15.—Cross-section showing the action of drains at different depths and distances apart upon retentive and unretentive soils.

ter Enters a Tile-Drain," that the line of saturation on either side of the drain is a curved line, and that this line, or, more properly speaking, the water-table, varies in height according as the soil is completely drained or only partially so. The line of saturation may be as represented by the line *bb*, or it may descend much more sharply towards the drain, as is represented by *cc*. The difference in these curves is caused by the nature of the soil. In the first case the soil is light and easily penetrated by water, and but little resistance to the flow toward the drain is offered by the soil. In the second case the soil may be clay, very retentive of water, and in its nature will

not allow water to flow towards the drains except at a steeper incline. In this case a portion of soil between the lines of tile is left undrained, which, in the case of a more permeable soil, would be well drained. Some writers assert that there is no lateral flow of water through the soil towards the drains, but a few experi-

ments and careful observation will prove the contrary, and the truth of the reasoning herein given.

It will be seen that the kind of soil to be drained governs the depth at which the tile should be laid, and also the proximity of the lines to each other, when we consider the thoroughness of the drainage.

The advantages of deep drainage are, first, a greater amount of soil is made available to crops, and fewer ill effects are felt from drought; second, there is room for more water in the soil in times of heavy rainfall, so that water may rise considerably above the drains for a short time without seriously affecting the crops. Suppose the drains are located at *ttt* (see figure). The soil becomes drained no deeper than the floor of the tile. In time of heavy rain the water can not pass off as fast as it falls, and of course saturates the earth much above the drains, and often to the surface. In this case the tiles must be much larger, so as to carry off the water nearly as fast as it falls, if we wish to keep depth enough of drained soil so that no injury for the time being may be done to the crops. This will many times account for the cry often made, "My tiles are too small." The same tile placed deeper, thereby giving a larger reservoir in which to collect drainage water in times of heavy rains, would often remove the difficulty.

We have thus far been general in the discussion of depth. The question will be asked, "What particular depth is most preferable, all things considered?" If we are careful to lay out grades to the best advantage, our depth will vary much with the inequalities of the surface. From the experience of many, it has been found that a depth of from 3 to 3½ feet in prairie soil is most desirable. It will be found that some portions

will be laid four feet deep and others only three feet, or even less, if we aim at a general depth of $3\frac{1}{2}$ feet. The expense of digging the ditches for four-foot drains is much greater than for three-foot drains, so that for general purposes of farm drainage the above instructions may be regarded as the best that can be given. It is not always possible, however, to obtain the desired depth, because of the shallow outlets which farmers are sometimes obliged to use.

Distances Apart.—According to the principles already noticed, drains in a retentive clay soil must be placed nearer together than in ordinary vegetable loam, if we wish to drain all the land between them. Even then the water-table will not recede so near to the floor of the drain as when the water percolates more freely and rapidly through the soil. In our experience, drains placed 100 feet apart in our loamy soil, and $3\frac{1}{2}$ feet deep, will thoroughly drain the land where the surface is ordinarily flat. It has been found that so easily and rapidly does our soil drain, there is no necessity for such close proximity of drains as is used in the East.

If, however, the soil is very retentive, especially near the surface, a distance of from 50 to 75 feet may be required to give thorough drainage.

Let us now sum up the subject of Depth and Distance Apart of Drains. The line *aa*, fig. 15, may represent the water-table when the soil is not retentive to any great extent, and is completely drained. This water-table takes different positions, as *bb*, depending upon the quantity of surplus water in the soil. In this kind of soil the drains may be placed 100 feet apart. Suppose that the drains are placed at this distance in a very retentive soil, as is one which is largely composed of clay, and we have left between the drains a portion

of soil which is undrained. This is shown by the line *cc*. The water-table rises from the drain more abruptly, owing to the greater resistance of the soil, which limits the width of land acted upon by the drain. This requires the drains to be placed nearer together. The line *ee* rises higher between the drains, because of the nature of the soil; hence the drains must be placed nearer together. It is not necessary, perhaps, to give any demonstration of the curves from laws which govern them. The statement of the fact of their existence is all we shall attempt at present.

We have been more lengthy in the discussion of principles than in laying down definite rules, for the reason that a good general knowledge of the principles will enable the farmer to determine the matter for his own particular case, where definite rules would not apply.

SIZE OF TILES.

It has been previously stated that the grade of the drain affects the velocity of the flow of water, and consequently the quantity which will be discharged in a given time. In consequence of this the grades of the drains which we wish to lay should be known before we can determine the most economical size of the tile to be used in order to drain a field or farm. In the consideration of this subject we shall endeavor to give a few practical directions, which have been found to be reliable, without entering into the mathematical demonstration of formulæ, which would not be of use to the farmer in ordinary drainage. The questions to be taken into consideration relating to this subject are:

1. What is the area to be drained?
2. What is the greatest rainfall upon that area in twenty-four hours?

3. What is the amount of surplus water which must be removed from the soil by drains, compared with the rainfall?

In the case of *casual* or *random* drainage, by which we mean the laying of a line here and there to drain some sag or wet place, and of which there is a great deal done, and often necessarily, there is a much greater area to be drained by one line of tile than we are apt to suppose. The one line will act directly upon a strip of land fifty feet wide on either side of it (in prairie soil), giving thorough drainage, and indirectly on all the land whose surface slopes toward the drain. In case of ponds and sloughs, a great quantity of water, in times of heavy rains, passes very rapidly over the surface of surrounding slopes and gathers upon the lowest land through which the drain passes. There is also a constant percolation of water through the soil upon the slope towards the soil which is directly acted upon by the drain. This has before been described as natural under-drainage. This being the case, we have found by experience that the area which we should consider in fixing upon the size of the tile is, in addition to the land acted upon directly by each drain, about one-third of all the land beyond this which slopes toward the drain, provided the slope is three feet or more in one hundred feet. The less the slope the more we may decrease this amount. For example, suppose the land, which is directly drained (taking fifty feet each side of all the drains), is two acres, and the sloping area beyond this is nine acres, then the area for which we must provide drainage is about five acres. A failure to consider the drainage area in this way has often led to the use of tiles which are too small.

If the land is flat and the drains laid out systematically, the area drained is easily determined. In such cases we need only to remove the water which falls upon the district itself. If, however, this district has land around it which slopes toward it, thereby throwing water upon it which does not properly belong there, we must regard the area in the same way as in the case of casual drainage. The *average* rainfall does not enter into this computation, but the greatest rainfall at any one time. If we can provide for the removal of the surplus water which falls during twenty-four hours, in the succeeding twenty-four hours, it will not do serious injury to the crops.

To find what this maximum quantity is, an actual record of the rainfall at this place (Tonica, La Salle county, Ill.) during the summer of 1880, will serve to show what we may expect. The table gives the rainfall in inches for the twenty-four hours previous to the morning of the day given in the column of dates :

APRIL.		MAY.		JUNE.		JULY.		AUGUST.	
Date.	Inches.	Date.	Inches.	Date.	Inches.	Date.	Inches.	Date.	Inches.
Apr. 2	0.08	May 9	1.20	Jun. 6	0.80	July 5	0.90	Aug. 2	0.30
" 3	0.23	" 10	0.94	" 8	0.10	" 8	0.30	" 20	0.28
" 4	0.21	" 20	0.28	" 9	0.37	" 19	0.20	" 24	0.63
" 14	0.09	" 21	0.09	" 14	1.45	" 20	0.02	" 25	0.05
" 16	0.45	" 27	0.00	" 15	0.40	" 23	0.44	" 27	0.65
" 17	0.28	" 30	1.79	" 25	0.64	Aug. 1	0.10	" 28	2.10
" 19	0.36	" 31	1.18	" 27	0.19			" 29	1.80
" 24	0.70	Jun. 1	0.30	" 30	0.50			" 30	0.30
" 25	0.56			July 1	0.14			Sept. 1	0.20
" 26	0.02								
" 28	0.18								

It will be seen that there are five days in which the rainfall was over an inch, and one day when it reached 2.1 inches. It is usually considered that one inch of rain in twenty-four hours is the maximum for which it is necessary to provide. The very excessive rains are quite apt to come after the soil is quite dry, and a great amount is absorbed. As this is not always the case, we should not be safe unless we assumed that one and a half inches would at times fall during twenty-four hours. This will give us 40,731 gallons which fall upon one acre of land.

The next question is, what part of this water is used by plants and carried off by evaporation, and what part must be removed by drainage? Many experiments have been made to determine this, and the amount discharged by drains has been found to vary much with the soil. We may say, in general terms, that about half the rainfall should be carried off through the drains. For a rainfall of one and a half inches we must remove 20,365 gallons of water from each acre, and this must all pass through at least a part of the main drain. The depth to which the land is drained and the nature of the soil will vary the conditions, so that the amount of water to be taken off may be much less. The fact that the soil when drained to a depth of three or four feet will hold an immense quantity of water, which will not, for the time, interfere with growing crops, allows us to use much smaller tiles than if we were required to remove all of the surplus water in twenty-four hours, and also renders close calculation as to size very difficult. As noted before, deep drainage requires tiles of less capacity for the same area than shallow drainage. The following directions may be given as a general guide in regard

to the size of the main to be used for a given number of acres. We will take as a basis drains laid not less than three feet deep and on a grade of not less than three inches in one hundred feet. For drains not more than five hundred feet long a two-inch tile will drain two acres. Lines more than five hundred feet long should not be laid of two-inch tile. A three-inch tile will drain five acres, and should not be of greater length than one thousand feet.

A four-inch tile will drain twelve acres.

A five-inch " " " twenty acres.

A six-inch " " " forty acres.

A seven-inch " " " sixty acres.

A long drain has a less carrying capacity than a short drain of the same size tile laid upon the same grade. In order that the long one shall do as effective work as the short one, larger tiles must be used if the grade remains the same. If we double the grade per one hundred feet of the drain we increase its carrying capacity about one-third. Hence, the steeper the grade the smaller the tile required to do the same work. In the above we have had reference to the size of the *main*. The size of sub-mains and branches must be proportionate to the size of the main, taking into consideration the fact that the capacities of tiles laid upon the same grade are to each other as the squares of their diameters. Thus the capacity of a two-inch tile is to the capacity of a four-inch tile as four to sixteen. The size of the tile should diminish toward the upper end of the main or branch according to the decrease in the amount of water which will need to pass through that portion of it. In case the drains are laid only from twenty inches to thirty inches deep, we can not expect that the sizes we have given will do satisfactory work,

especially in times of heavy rain. The instructions given upon this subject are as definite as is desirable to give, unless we take up special cases, in which we must vary the general rules. A man who has had large experience in laying out drains would, of course, do it more economically than the inexperienced, for he could take into account the grades upon which the drains were to be laid, the nature of the soil, and the area to be drained. In this subject we have not in all cases given reasons for statements made, since that would take more space than seems desirable at this time, but they may be relied upon as generally true respecting the subject under consideration.

KIND OF TILE.

The tile selected should be well burned, being hard enough to ring when struck with a knife blade. It is not well to get those which have been drawn out of shape by excessive heat in burning. They should be smooth on the inside, as the friction will be less. The best shaped tile, all things considered, is that in which the cross section is a circle. They can be laid more easily and give greater capacity for the material used. The requisites then are circular tile, of good clay, well burned, smooth and true in shape.

CONCRETE TILE.

While tiles made of burned clay have been well tried and are safe where draining is practicable, a concrete tile has been introduced during the past year, which promises to serve an excellent purpose. It is manufactured by means of a simple machine, which is operated in the ditch after it has been dug and graded in the usual way. The materials used are the best quality of hydraulic cement, lime, and coarse sand.

These are mixed in proportions suitable to the work and made into a stiff mortar. The mortar is fed into the machine through a hopper and comes out at the rear end of the machine a continuous pipe, smooth inside and outside. By means of a trowel made for the purpose, the continuous pipe thus made is cut into sections of any desired length, in such a way that the bottom is left continuous, yet sufficient crevices are left for the entrance of water. The cement soon sets, and in a day is hard enough to bear the weight of the filling without crushing. When fully hardened, the tile has the durability of stone. The machine and material are not very expensive, and the farmer will find it to his advantage to investigate this new tile and its manufacture. So far, it lacks the tests of time and experience to prove its desirability, yet in the writer's opinion it will serve an excellent purpose in many places, especially for continuous water pipes about the barn and dwelling.

CHAPTER V.

PRACTICAL DETAILS OF THE WORK.

Mapping Drains—Construction of Drains, Grading the Bottom, Outlet, Laying Tile—Difficulties in Constructing Drains—Obstructions to Drains—Junctions.

MAPPING THE DRAINS.

The drains having been staked out upon the ground, the grades arranged, and the size and number of tile fixed upon, we should make a map of the drains which will show their position, length, fall per 100 feet, and the physical features of the land through which they pass. This, with the notes, will give all the information respecting the drains which it will be necessary to preserve. The map is merely a sketch showing the position and length of the drains, like the one shown in fig. 16; can be easily made; will show what has been done, and will serve as a record of the improvements in the drainage line, just as others are shown by houses, barns and fences. One may think he does not care for a map of his drains, as they will show themselves in the condition and improvement of the soil, yet when he begins to forget their location he will wish that he had some representation of them to refresh his memory and to show his friends, if nothing more.

THE CONSTRUCTION OF DRAINS.

The work done thus far has been preparatory to the actual digging of the ditch and laying of the tile. It will seem to many that the staking out, leveling and

adjusting the grade of drains, is too much work for little pay, if not wholly useless. The farmer, perhaps, has seen his neighbor do some draining "by guess" which has worked well, or he may have laid a short line of tile himself with good results, by simply using the running water as a guide. In more extended sys-




Fig. 16.—Map of a Drained Field.

tems, and with no water, or even with water for a guide, he will sometimes partially or entirely fail. "Be sure you're right and then go ahead," is the motto to use in draining. With the drains laid out and depths marked upon the stakes, and every thing arranged as it should be, we know in advance that the drains will work perfectly, if they are laid according to the survey. If the whole system is not completed at one

time, a part can be done in one year and the rest the next, or any other convenient time, though it is better to do it all at once, as the frost will move the grade pegs so much that the unfinished part will be obliged to be leveled again. It is better, however, to do part of the leveling twice if necessary, rather than not have the drains laid out upon some connected system.

Digging the Ditch.—The tools which are necessary to do good and rapid work are, First, a ditching spade for the main part of the digging. This spade has a



Fig. 17 - Tile Hoe

blade about eighteen inches long, a little narrower than the common spade, and curved towards the front. The superiority of this over the common spade is that it is capable of taking narrower and deeper

drafts, which will adhere to the spade until it can be lifted out. Secondly, a tile spade, which is narrower than the ditching spade, and tapers towards the point. Third, a "pull scoop," or tile-hoe, for cleaning the bottom of the ditch. The handle of this should be at such an angle that the workman can use it when standing in the ditch sixteen inches from the bottom. As this is a very handy tool, and it is often necessary to get it made by the blacksmith, we give a drawing of it (fig. 17). It is most convenient when it is just large enough to make a channel into which the tile to be used will fit firmly. This would necessitate a different hoe for every different sized tile. A tile-hoe suited to three-inch tiles may be used for much larger sizes, with a little care and extra work. Fourth, a gauge, which is a stick six feet long, and one and one-fourth inches square in section, graduated to feet, inches and eighths

of inches, and having an arm two feet long, which slides up and down upon the graduated stick. The arm should move at a right angle to the stick and fasten at any desired point by means of a thumb-screw. Fifth, a strong hemp line 100 feet long, for lining out the ditch, and also for a gauge line to be used in grading the bottom of the ditch.

Begin opening the ditch at the outlet. Stretch the line about four inches from the grade pegs, and take out one draft with the ditching spade, making the ditch ten inches to twelve inches wide, where the ditch does not exceed four feet in depth. The ditch should be clean cut and straight on the sides. If there are short crooks when it is started at the surface, they are apt to increase as the ditch is deepened, so that the final channel for the tile becomes crooked to a troublesome degree. The workman should have in mind the depth which is marked upon the stakes, between which he is working, and in digging he should aim to leave a bottom spading of sixteen or eighteen inches for the one who finishes and grades the bottom. We are supposing that the soil works easily, not being hard enough to require picking, when we give ten or twelve inches for the width of the ditch at the top. If the soil is so hard that the spade can not be pushed down its full length, or it must be loosened with a pick, more width must be allowed—sometimes even twenty inches—at the top, the ditch in all cases slanting in, of course, toward the bottom, to the width of the tile.

Grading the Bottom.—The ditch having been dug to within sixteen inches of the bottom, as near as the workman can judge, we must take out the last draft with the tile spade, and bring the bottom to a true grade and depth, as indicated by the stakes. These,

we remember, give the depth measured from the grade-peg. It remains for us to connect these points so that the bottom of the ditch shall be a true line upon which we may lay the tile. There are many ways of doing this




Fig. 18 - Grading the Bottom.

correctly, but we give only one, which has been found simple, easy, practical and correct, and which is a favorite method with all who have used it. It consists in stretching a line at the side of the ditch at any convenient height parallel to the required bottom of the ditch, as shown in fig. 18. In order to do this, we take the gauge before described, a convenient length of which is six feet, though, of course, for very deep ditches it must be longer. In a four-foot ditch we may set the arm of the gauge at six

feet. Now, noticing the number of feet and inches marked upon the first stake, subtract it from six feet, and note the difference. Drive a stake, *a*, by the side of the grade-peg until the distance from the top of the peg to the top of the stake *a* is the same as this difference. Set another stake at the next grade-peg in the same way. Stretch the line over the tops of these stakes and fasten

by small pegs, as shown in the cut. The line is now parallel to the line upon which we wish to lay the tile, and six feet above it. It may be set any other convenient distance above the bottom by the same method. If the line sags, place a stake under its middle. Take out the last draft with the tile-spade, being careful not to go too deep. Dig as far at a time only as you can conveniently reach back over with the tile-hoe, and then, without stepping down to the bottom of the ditch, clean out the loose dirt with the tile-hoe. Have the gauge at hand, and holding it in a vertical position, see what is necessary to make the bottom parallel with the line. Then pare the bottom down until the arm of the gauge when again placed will just graze the line. Test every foot along the bottom, and do not leave it until it is right. A little water in the bottom of the ditch causes the soil to work easier, but more than two inches is a hindrance to good work. The digging may go on in this way, the workman being careful not to walk in the ditch after it is prepared for the tile. The line is set from stake to stake as the work proceeds, due care being taken that everything is right.

Laying the Tile.—Before the ditch has been graded far, it is best to lay and cover the tiles, to prevent hindrance by the falling in of earth. Begin at the outlet and lay the tiles by hand, turning them about until the ends fit closely upon the top. If the bottom is firm and hard, the workman may stand upon the part already laid, for the tiles should fit true and solid in the groove made for them. Be sure that they are turned until they fit well. This is an important part of the work, and must not be slighted. When the work of laying stops, while more ditch is being prepared, the

upper end of the drain should be protected from mud which may be washed down as the digging proceeds. If the bottom of the ditch is soft, the tiles may be laid from the surface with a tile-hook. Workmen who do job work prefer this, as the work is done easier and faster, but for excellence of work we prefer the hand laying. The upper end of each drain should be closed by placing a stone or brick over the end of the tile before covering. The tiles when laid should be imme-




Fig. 19 - Outlet

diately covered with moist clay, which has just been taken out, or is obtained by slicing off from the sides of the ditch with the spade. This should be firmly pressed about the tile with the feet to a depth of six inches.

One of the first things to attend to is to secure the outlet from injury by trampling of stock, etc., and the entrance of vermin. If long delayed, water may flow through the tile, and seriously interfere with any work at the outlet. We give an illustration of a good way to secure the outlet from injury in fig. 19. Dig a pit two feet square where the outlet is located, and lay a foundation of stone deep enough to be safe from frost. Build this up to the line of the drain, laying the stone

in cement and sand mortar. Lay the first two tiles upon this, being careful that they connect correctly, and continue the stone work to within one foot of the surface. A grate may be placed a little distance in front of the end of the tile, and fastened as the masonry proceeds; or the outlet tile may be larger than the others, and have wires passed through holes drilled in the tile for that purpose. Brick may be used instead of stone, or even wood will be good as long as it lasts.

After the tiles are first covered the ditch may be filled in in any way which may seem desirable. If the earth is dry, it can be done with about one-half the expense required when wet. All of the earth should be heaped upon the ditch, as when it settles there will not be too much. When done by hand a simple and expeditious method is to pass a rope around the blade of a large scoop-shovel, then with one man pulling at the rope on one side of the ditch, and another pushing upon the handle upon the other side, the earth can be moved rapidly.

We have described only one way of performing the work. Many practical workmen in drainage may take exceptions to it, and recommend a better way. Any method which is well understood and gives good results is apt to be regarded as the best. That which we have described has been demonstrated by actual use to be practical and correct.

DIFFICULTIES IN CONSTRUCTING DRAINS.

At some seasons ditches may be dug with less expense than at others; but the most favorable time can not always be selected. The clay subsoil may be dry and hard, necessitating slow work, and sometimes the

pick must be used. Under such difficulties the ditch should be 14 to 20 inches wide at the top, that the workman may have room for his arms and shoulders. If, on the other hand, the earth is so wet that it will "slump in," the sides must be sloped from the surface at such an angle that they will stand. Another way to overcome this difficulty in deep ditches is to "sheet," by driving two-inch planks endwise at the sides of the ditch until the lower ends are below the bottom of the required ditch. The planks may be kept in place by cross braces above, and the earth taken out between the lines of "sheeting," and the tile laid to grade. The planks may be taken up and another section prepared in the same way. This method is to be resorted to only in deep ditches opened in very unstable and treacherous soil.

If the soil or subsoil is a wet silt, quicksand, or other material which "runs," the joints of the tiles should be covered with firm clay, or a band of grass or straw. This will keep such material out of the drain until it has made the soil sufficiently dry and firm to give no trouble from this source. If the drain can be put in position and the earth compacted about it without moving the tiles, there is little to fear concerning its success and durability.

It is often desirable to drain a spring, but the earth is usually so soft that the tiles can not be placed in position. In such cases a bottom can be most easily made by placing a fence-board for the tiles to rest upon, observing to have the tiles laid upon the proper grade, and to cover them with a few inches of firm earth to hold them in place and prevent mud from obstructing the drain. Gravel-stone or clay may be

used for a bottom with good results, but they are not always easily obtained.

OBSTRUCTIONS TO DRAINS.

Drains are sometimes obstructed by the roots of such trees as the willow, the water elm, etc. Experience has fully proved that a tile drain is not safe near willows. The fine roots penetrate the line at the joints, and flourish with such luxuriance that in one or two years the tile will be entirely filled with rootlets. The only safe way is to destroy all such trees within seventy-five feet. For a properly constructed drain, the only care it requires is to keep the outlet free from mud, remove the silt which accumulates in the silt-basins, and to see that no trees with water-loving propensities are permitted to obstruct the drain with their roots.

JUNCTIONS.

Great care should be taken in making junctions with other drains, that the joints be good, and that the branch drains always discharge in the direction of the current of the main drain. Right-angled junction tiles should not be used. Junctions should be so made that the branch will enter at an angle of about 30° with the one into which it flows; or if a greater angle is necessary, the mouth of the branch tile should be curved. In fig. 20 are shown sections of junctions by which the truth of the above remarks may be made more apparent. No. 1 is a section of a right-angled junction. Suppose that the two currents meeting at *a* be represented by the lines *ab* and *ad*; the velocities being equal, the lines are made of equal length. Completing what is termed the parallelogram of forces, *abcd*, and drawing the resultant *ac*, we have the direc-

tion of the current resulting from the union of the two. This resultant, it will be seen, flows strongly against the opposite side of the tile, checking the current by the friction thus caused, and also creating a little eddy in which earthy material washed out by the drain may be deposited. If the velocity is greater in the branch, as is often the case, we find the resultant in the same way, by making the length of the lines proportional to the velocity of the currents we have to represent. Supposing the velocity of the current in




Fig:20 - Junctions

the branch to be twice that in the main. The resultant *ae*, in No. 1, shows that there is still greater resistance offered than in the first case assumed. The best form for a junction which joins a branch to a main at nearly right angles, is shown in No. 2. This curves the current gradually as it enters the main stream, uniting it with the main current in a way that accelerates it rather than retards it at the time the two unite. No. 3 shows the resultant of the two currents when they unite at an angle of 30° , which is the preferable angle. A study of these figures will show the necessity of careful attention to this subject.

Many mistakes have been, and are still being made

by western farmers in the practice of drainage. Among them we notice, first, faulty and insufficient outlets. This is a difficulty always present where the land is flat. The remedy is for farmers to unite and construct large and deep open ditches, into which tile-drains may discharge freely. Second, the use of tiles too small for their subsequent work. The sizes given in a previous chapter are small enough. If the grade upon which they are to be laid is decreased, the size of the tiles must be increased, in order to do the same service.

We have considered the subject of drainage simply in its application to land for agricultural purposes. We have not attempted to exhaust the subject, or to discuss a variety of opinions and practices, but to give simply the principles underlying it, and a practical method of carrying them out. The methods of calculation used by drainage engineers have not been entered into, only to an extent which may be of use to the careful farmer. The cost of drainage and the profit to be derived from it are matters upon which almost every one can satisfy himself by consulting with those in his vicinity who have had some experience in the work. If whatever is done be done well, we have no fear in asserting that the result will surprise our western farmers, and will so add value to prairie farms for agricultural purposes that it will be considered the most important improvement that can be made upon them.

CHAPTER VI.

DITCHING MACHINES.


Difficulties Involved—Principles—The Johnson Tile Ditcher—
The Blickensderfer Tile Drain Ditcher.

There has been considerable effort, during the last few years, to lessen the expense of ditching for tile-drains by the invention and use of machines. The success thus far attained is very encouraging, and it is to be hoped that soon the machine will very largely supplement hand-work in ditching. There are many difficulties incident to the digging of farm drains. The soil is often soft and sticky; at other times it is hard, and in some localities contains gravel and stone; deep cuts must sometimes be made; springs must be drained; in short, the difficulties to be overcome by the inventor of a tile ditching machine can hardly be appreciated by any one unacquainted with practical ditching.

There are essentially two different principles upon which the machine problem is being worked out. One is the repeating process, by which the machine is made to pass back and forth over the ditch, each time adding to its depth until it is completed. The other completes the ditch as the machine advances, requiring only one passage over the ground.

The following cut represents a repeating machine, called the Johnson Tile Ditcher, manufactured by King, Hamilton & Co., Ottawa, Illinois. The machine is drawn by eight horses, four abreast. A revolving wheel containing small spades loosens the earth and it

is elevated and thrown on one side of the ditch. At each passage of the machine over the ground, the depth of cut is uniform and the ditch is completed with a



regular grade where the necessary care is observed. The manufacturers claim that they can cut from one hundred to one hundred and fifty rods of three-foot ditch per day with this machine, and leave the bottom in good shape to receive the tile.




Fig. 22—The Bickensaderfer Tile Drain Ditching Machine.

The cut on page 74, represents the Blickensderfer Tile Drain Ditching Machine, manufactured by U. Blickensderfer, Decatur, Illinois,* which consists of a large revolving wheel of excavators or buckets mounted upon four wheels. The buckets are of a new and peculiar shape of construction; they grow larger inside from their mouth or cutting edges back, and as the clay is scooped up and passed in, not being compressed, but getting into larger space in the back of the buckets, it readily drops out when revolved to the top of the wheel, the earth being thrown on an inclined apron to one side of the ditch. Curved teeth or picks of steel, projecting beyond the buckets, loosen hard-pan clays and protect the buckets from stones, which they also lift and work out by a simple manipulation of the revolving wheel, the forward motion of the machine being readily checked or backed during the operation without stopping the horse.

The manufacturer of this machine claims that it will cut a ditch over four feet deep in one passage over the ground, and at the same time give any desired grade over an uneven surface, the grade being as perfect as a person can sight the top of a row of stakes set to indicate the desired grade.

The power consists of a single horse, used upon a sweep around the machine, which revolves the buckets and at the same time moves the machine ahead, requiring only one man and a boy to attend it. It will cut from seventy-five to one hundred rods of ditch per day, finishing it accurately for the tile. The bottom of the ditch is shaped so that a large or small tile will fit it and not roll or get misplaced.

These, as well as other machines for digging ditches,

*Formerly Erie, Pa.

are worthy of close attention on the part of tile drainers. If they are not yet already satisfactory in every respect, it is quite probable that one or all of them will soon take the place of hand-ditching, at least in many kinds of soil. The outlook for reclaiming our waste lands and the improvement of cultivated farms is very promising when we consider the impetus which successful tile and ditch machinery is giving to this progressive work. The old adage "Nothing succeeds like success" has proven true in the history of draining, and will also be true of the ditching machine which once shows to the people that it is a success in the way of doing good work at less cost than it can be done by ordinary hand work.

CHAPTER VII.

COST AND PROFIT.

Cost of Drainage—Cost of Mains—Profits of Drainage.

COST OF DRAINING.

The first cost of draining is what frightens many farmers when the subject is brought to their notice. Draining should be regarded as an investment of capital. The farmer's land, his necessary stock and implements, and his yearly labor are regarded as his capital. All that he can make by the management of these is the profit of his business. But to drain, cash capital is required. If the farmer does not possess this, and can not get it at a reasonable rate of interest, he can not drain. If he has been prosperous, and, as a result, he has in his possession a little cash capital, he does not hesitate to use it in adding to his facilities for increasing his profits. Nor does he hesitate long to pay a reasonable rate of interest for money with which to add to his working force if he can see that there is a fair prospect of making a much larger profit than the rate of interest he is obliged to pay.

Without naming a definite number of dollars and cents, let us take this general statement, which is admitted by all who have drained to any extent, that on ordinary farm land that will produce but one-fourth to one-half a crop, the total cost of draining will be met by the additional crop that will be produced during the next two years after draining. The cost of cultivating drained land is less than for wet land, as

all who have tried both will admit. By this investment the farmer will get fair wages for what work he does upon his land, his money will be in his pocket again at the end of two years, and his land drained and ready to return his money every succeeding two years. Many farmers cultivate land which, in reality, does not pay them a fair remuneration in the crop they get from it. Their profits come from land which is in good condition and will produce good crops. Very often they would make more to wholly discard the wet land and give more labor to that which will give some return for it.

Where land is worth fifty dollars per acre, it will pay a large return to drain wet land. It is true that much western farming is done on cheap land where it is the custom to cultivate a part of the farm, which is naturally surface-drained, and use the rest for grazing purposes. Draining under such conditions will not pay, because the farmer has not the facilities for using the good land he already has in his possession. Such farming, however, is fast coming under the more advanced system in which "more work and less land" is the motto.

The cost of draining, like any other enterprise undertaken upon the farm, will always vary with the price of labor, yet farm products usually bear a price commensurate with farm labor, so that the relation of the two will be about the same. There are two things which will vary the expense of draining whatever may be the relation between farm products and farm labor. These are: the main drains, which will necessarily vary in size, length and depth, and the degree of thoroughness with which draining is done.

COST OF MAINS.

It will be easily understood that a field or farm may be so situated that very little expense will be required for large mains into which to discharge the laterals. It may be for the reason that the field is near some large open ditch, or some stream which is easily reached. Draining will then be reduced to a minimum expense. There are often cases where a main drain of considerable size must be long and laid deep in order to give the necessary outlet to the field.

It is the custom of ditchers to dig ditches and lay tile by the rod, though a more convenient unit would be the foot or one hundred feet. As a basis, we will say that ordinary diggers can be had for \$1.50 per day, and good ditchers at \$2.00 per day. For a main drain, laid at different depths and with tile of different sizes, the expense per one hundred feet is as follows:

Cost of Five-inch Main per One Hundred Feet.

Depth of Ditch.	Cost of Digging and Laying.	Cost of Tile.	Cost of Filling Ditch.	Total Cost per 100 feet.
3 feet.	\$1 50	\$3 00	30 cents.	\$4 80
4 feet.	2 00	3 00	42 cents.	5 42
5 feet.	3 00	3 00	60 cents.	6 60
6 feet.	4 50	3 00	75 cents.	8 25

Cost of Six-inch Main per One Hundred Feet.

Depth of Ditch.	Cost of Digging and Laying.	Cost of Tile.	Cost of Filling Ditch.	Total Cost per 100 feet.
3 feet.	\$1 50	\$4 00	30 cents.	\$5 80
4 feet.	2 10	4 00	42 cents.	6 52
5 feet.	3 00	4 00	66 cents.	7 66
6 feet.	5 10	4 00	78 cents.	9 88

Cost of Seven-inch Main per One Hundred Feet.

Depth of Ditch.	Cost of Digging and Laying.	Cost of Tile.	Cost of Filling Ditch.	Total Cost per 100 feet.
3 feet.	\$1 80	\$6 00	36 cents.	\$8 16
4 feet.	2 40	6 00	48 cents.	8 88
5 feet.	3 00	6 00	72 cents.	9 72
6 feet.	5 70	6 00	90 cents.	12 60

Cost of Eight-inch Main per One Hundred Feet.

Depth of Ditch.	Cost of Digging and Laying.	Cost of Tile.	Cost of Filling Ditch.	Total Cost per 100 feet.
3 feet.	\$1 92	\$8 50	42 cents.	\$10 84
4 feet.	2 58	8 50	54 cents.	11 62
5 feet.	3 90	8 50	78 cents.	13 18
6 feet.	6 00	8 50	\$1 00	15 52

These tables give a pretty close estimate of the cost of mains in general, when wages are two dollars per day for good ditchers. To this should be added the cost of boarding the men while they are at work, and

of hauling the tile from the factory, or station to which they are shipped. The estimate for filling the ditches is made on the basis of part being done by hand and part by team work. It is often the case that ditches can be filled with but little expense by using a steady team with a plow and scraper. When it is necessary to dig the ditch five or six feet deep, the risk of striking rocks, hard clay or quicksand makes the estimate more unreliable, and it will be found in such cases that the cost of digging the ditch and laying the tile will run over, rather than under, the estimate.

It should be clearly understood that these items of cost will vary greatly with different years and in different localities. The cost of tile and labor are not the same for two years in succession, hence the foregoing estimate must be varied with such changes.

The actual cost to the farmer may be greatly diminished by "taking time by the forelock," getting his plans well laid, and when his farm help is not rushed with work, let them devote their time to the drains. There are winters which are often so free from cold weather that ditching can be done to good advantage if the tile have been previously hauled. Help is then plenty and cheaper than during the summer months. There are other seasons of the year when the forces of the farm can be used with economy in carrying on drainage work.

COST OF BRANCH DRAINS.

Branch drains, laid from three feet to three and a half feet deep, in ordinary farm land, which will spade easily, will cost \$2.00 per one hundred feet for digging the ditch, laying the tile and filling up

the ditch. Three-inch and four-inch tile cost from \$1.32 to \$2.00 per one hundred feet respectively. Add to this the cost of boarding the men while engaged in the work, and of hauling the tile to the ground, and we have a close approximation of the cost of draining per one hundred feet. There are a few incidental matters, such as protecting the outlet tile, silt basins, if any are needed, and surveying, which should be taken into account.

The actual cost per acre will depend upon how many rods of drain are laid upon an acre. A field having several wet places and always troublesome to cultivate in the spring, to say nothing of the loss incurred, can often be drained out in good shape at a cost of about five dollars per acre for the whole field. The cost of draining a field by placing the laterals from sixty feet to one hundred feet apart, making a fair allowance for the extra cost of mains, is from fifteen to twenty dollars per acre, at prices as they exist at the present writing (1882).

PROFITS OF DRAINING.

Enough has been said incidentally, in the foregoing pages, concerning the profits of draining, to satisfy owners of wet farming lands, that it is better to reclaim such lands than to invest capital by buying new farms. After having arrived at the probable cost of the work, it will be easy to estimate the increase of crops by comparing the field to be drained with one which is naturally drained, and whose productive powers have been well ascertained. If the land is in such a condition that it will produce nothing without draining, the entire crop, after deducting the cost of producing, will be profit. We will suppose that an undrained field will produce twenty bushels of corn per

acre. If well drained, the same labor and expense in cultivating will produce fifty bushels of corn per acre. Here is a gain of thirty bushels per acre, which, at forty cents per bushel, will be twelve dollars per acre as profit. The labor, which in the first case produces eight dollars, in the second brings twenty dollars. Other crops can easily be figured in the same way, and such results are realized every year by farmers who have drained in an economical and thorough way. The farmer will have more confidence in his work if he investigates and figures for himself. Let him estimate the cost carefully and compare it with the expected gain. We do not advise any one to go at this work blindly, or because others say it is all right. Count the cost and the expected increase fairly, and then shape your course accordingly.

We can give in a sentence the condensed evidence of scores of farmers upon this subject of profit, viz: that *draining pays from twenty-five per cent. to fifty per cent. on the investment*. The writer regards it as almost superfluous to publish individual statements regarding this subject, as they can be found in almost every paper published in the interest of farmers. The aim of the author has been to tell how to drain in such a way that the best results may be obtained. The profits will be assured if the work is adapted to the case in hand and well done.

CHAPTER VIII.

ROAD DRAINAGE.

Improvement of Roads—Surface Drainage—Under-Drainage—
Effect of Tile Drains upon Roads—Care of Drained Roads.

ROAD DRAINAGE.

While the drainage of farm lands is of great importance as an aid in the production of large crops, the drainage and other improvement of our public roads may be regarded as meriting equal attention, since the farmer must have an opportunity to market his products, which is commensurate with their quantity.

Western roads are often impassable for loads during several months of the year by reason of the mud. There are, of course, parts of the West in which the roads are graveled, or are by nature good nearly all the year. To improve our roads, as we have them now, is an important problem. The arguments for gravel roads on prairie land have very little force considering the great distance from which gravel and stone must, in most cases, be brought, and the consequent expense. Were the gravel at hand, it could not be used for the construction of roads until a firm foundation had been prepared for it by drainage.

Let us take the roads as they are and improve them by using the means within our reach. All that has usually been done to our roads in the way of improvement has been to make sloughs, ponds and swamps passable. An embankment has been made through these places by scraping the earth from either side to-

wards the middle of the road, leaving ditches about two feet deep, and making an embankment two or three feet high. Plank culverts are used in the sloughs to allow the water to pass through the embankment. The side ditches are often made with little reference to the discharge of the water which they collect from the road and adjacent fields. As a consequence these ditches remain full of water during a large part of the spring, saturating the bottom or the embankment until it is in a soft and plastic condition. The surface of the road becomes broken up by the frost as it comes out of the ground, the spring rains penetrate it until the saturated surface meets that of the bottom, and we have a mass of mud impassable as a road, and a discouraging contrast to the smooth and firm road enjoyed by travelers the summer before. As the water evaporates, or slowly drains off through the soil, the road begins to dry and in process of time becomes firm but rough, the track full of ruts, which will hold water to their full capacity at every rain-fall, while the embankment is flattened, and perhaps hollow in the middle. The road is annually repaired by raising the embankment a little with newly dug earth, and the process goes on from year to year.

IMPROVEMENT OF ROADS.

As before stated, we wish to take our roads as they are, and make them better by using the means within our reach. We may have our ideas of what perfect roads ought to be, and show what has been done towards their attainment in other localities; but yet our own roads will remain as bad as ever until we hit upon some system which will apply to our soil and particular need.

Owing to the readiness with which our soil absorbs water, there will be a time in the spring of the year when the frost is coming out of the ground, that the surface will be soft and not fit to travel upon, do what we will; but the length of the time during which this is the case may be greatly shortened by a proper system of drainage. As roads are now worked, they are unfit for heavy travel for two months or more in the spring. If drained, this time can be decreased at least one-half, the road be much better for the remainder of the year, and the expense for repairs be reduced to a minimum.

SURFACE DRAINAGE.

The most essential feature of a good road on prairie soil is a hard and smooth surface. When a road track upon prairie loam is examined, it will be found that for a depth of about ten inches there is a hard and compact crust, while below, the soil is as loose as that in a meadow. The value of the road depends upon keeping this crust intact. The road bed should be raised and sloped sufficiently from the center line towards the ditches, to carry off the rain-fall. If the road bed is not deeply rutted, the rain will flow off so rapidly that the road crust will not be badly softened. The incline from the middle in an eighteen-foot road should be about six inches. If the road is not embanked, the storm-water, even on naturally drained roads, will run down the slope in the road track until it is spoiled, and a new one must be made. The side ditches are valuable in collecting the water of heavy rains, and suitable outlets should be provided for them.

UNDER-DRAINAGE.

The object of under-draining a road is simply to keep the bottom of the embankment firm at all times of the year. The open ditches should carry off the excess of storm water, but it remains for the tile-drains to remove what the ditches fail to carry off, and to give a dry road crust. In under-draining a road, first obtain a good, free outlet for whatever drains may be needed. If there is any doubt upon this point, use the level to find the fall above and below the proposed outlet, before any further arrangements are made. Do not make the outlet at some little ditch which will soon fill up, but be sure that all the water that will ever be discharged from the drains can flow away without "backing up." It may be that the outlet must be obtained through a farm adjoining the road. In such cases the owner of the farm and the road authorities should unite in some equitable way.




Fig. 23.—Plan for Improving a Road by the Use of Tile Drains.

Supposing that the road is in flat, swampy ground, lay out a drain lengthwise of the road on each side of the embankment and close to its base, as shown in the

plan (fig. 23) and cross-section (fig. 24). The reasons for laying a drain at each side of the embankment, instead of one in the middle or on one side, are as follows: If one drain is laid in the middle of the road,




Fig. 24.—Cross-Section of Road with Two Drains.

all water which enters it must pass from the side ditches through the base of the embankment. In times of high water the drain will not carry the water away quickly enough, consequently the base will be, for a time, saturated. The idea that a drain in the middle will remove the water upon the road bed is erroneous, for at such times the mud is puddled and will permit no water to pass from the surface to the drain. One drain at the side of the embankment, though excellent, is often insufficient to give good drainage. Two drains laid in the way indicated in the figures will prevent all water from saturating the base of the embankment, even in the wettest times. The drains should continue as far as the ground is

wet to any extent in the spring.

If there are ponds near by, which, in times of heavy rains, overflow and discharge into the road, side drains should be extended to them, as shown in figure 23. Should there be a small hollow along the line of the

ditch, as sometimes happens, a catch-basin will facilitate the removal of the water. This is a pit two feet square, dug as deep as the tiles are laid. After the tiles are laid, the pit is filled with gravel and small stones. The object of this basin is to take the water which gathers so quickly in such places, and give it a rapid ingress to the tile.

The depth of the drains should be as near three feet as is consistent with the nature of the ground. As the important thing to look after is the rapid removal of water, special attention should be given to the manner in which the work is done. The grades, if possible, should not be less than three or four inches to one hundred feet. The principles apply in this work as in draining land for farm purposes, though the object sought is different.

The size of the tile should be larger than would be required for the draining of the soil for cultivation, for the reason that storm water is thrown rapidly into the side ditches from the surrounding soil, requiring the tile to carry much more in a short time than if the land were flat.

As suggestive of the size of the tile that it is best to use, we may give the following directions: For drains eight hundred to one thousand two hundred feet long, use three-inch tile; one thousand two hundred to two thousand feet long, four-inch tile; two thousand to three thousand feet long, five-inch tile. These directions apply to the two lines of tile along the road, laid upon a minimum grade of three inches per one hundred feet. If these do not discharge into an open ditch, the size of the tile in the outlet drain should be proportioned to the road drains.

EFFECT OF TILE DRAINS UPON THE ROAD.

The drains keep the embankment firm by preventing water from penetrating it from the bottom and sides. The whole of the road is kept dry, except the




Fig. 25.—Cross-Section Showing a Drain for Intercepting Water which Oozes from a Bank at the Road-side.

crust at the top, which, if traveled upon when wet, becomes puddled and will allow no water to go through. This part of the road bed must be made dry by surface drainage and evaporation. During the fall and winter the whole road embankment becomes thoroughly drained, so that there is only a little frost to come out and soften the surface of the road in the spring. If we could make embankments along our roads four or five feet high, we should consider our roads well drained. Instead of this, we withdraw the water to a depth of four

or five feet from the surface of the road, which gives it the effect of an embankment, as shown by the dotted lines *a b* in fig. 24. Draining does even better than this, for in the case of the raised embankment water often stands in the large ditches at the side; but

when the under-drains are laid, no water at any time stands higher than the drains.

It should be borne in mind that under-draining does not prevent rain from penetrating the surface and allowing the road to be cut into ruts; but this affects only the surface and for a comparatively short time.

A tile-drain may be used in many places to intercept water which percolates through banks lying higher than the roadway. One line of tile, laid between the bank and road, as shown in fig. 25, will often cut off the water at such a depth as to render a road firm which has previously been soft. Springs of water often make muddy spots in a road. The sources of such water should be hunted up, and drains laid where they will convey the water from the road.

The only hope we have for good roads on our prairie soil is to keep them dry by removing the water as quickly as possible from the surface, and preventing the substratum from becoming saturated.

CARE OF A DRAINED ROAD.

After the road bed has once been put into proper shape, and well drained, nothing should be done except to keep the surface in shape and as smooth as possible. The old crust is better than any new, and should be preserved with the utmost care. All improvement of the surface should be upon the "stitch in time" principle. When the road becomes rutted out and begins to dry, it should be smoothed by drawing over it some machine made for the purpose, of which there are several. If the drains are properly constructed, the outlet attended to, as in the instructions given on farm drainage, the road will require but a small outlay for improvements each year.

Road drainage has been experimented upon until its benefits have been fully proved. The work of draining many roads is limited because of the difficulty of securing proper outlets for the drains. Nothing will obviate this except hard and sometimes expensive work. It can never be expected that such roads will be good until they are drained in such a way that storm-water will pass quickly from the surface, and the sub-stratum be kept firm by thorough under-drainage.

SHORT-TITLE CATALOGUE

OF THE
PUBLICATIONS

OF
JOHN WILEY & SONS,

NEW YORK.

LONDON: CHAPMAN & HALL, LIMITED.

ARRANGED UNDER SUBJECTS.

Descriptive circulars sent on application. Books marked with an asterisk are sold at *net* prices only, a double asterisk (**) books sold under the rules of the American Publishers' Association at *net* prices subject to an extra charge for postage. All books are bound in cloth unless otherwise stated.

AGRICULTURE.

Armsby's Manual of Cattle-feeding.....	12mo, \$1 75
Principles of Animal Nutrition.....	8vo, 4 00
Budd and Hansen's American Horticultural Manual:	
Part I.—Propagation, Culture, and Improvement.....	12mo, 1 50
Part II.—Systematic Pomology.....	12mo, 1 50
Downing's Fruits and Fruit-trees of America.....	8vo, 5 00
Elliott's Engineering for Land Drainage.....	12mo, 1 50
Practical Farm Drainage.....	12mo, 1 00
Green's Principles of American Forestry.....	12mo, 1 50
Grotenfelt's Principles of Modern Dairy Practice. (Woll.).....	12mo, 2 00
Kemp's Landscape Gardening.....	12mo, 2 50
Maynard's Landscape Gardening as Applied to Home Decoration.....	12mo, 1 50
Sanderson's Insects Injurious to Staple Crops.....	12mo, 1 50
Insects Injurious to Garden Crops. (<i>In preparation.</i>)	
Insects Injuring Fruits. (<i>In preparation.</i>)	
Stockbridge's Rocks and Soils.....	8vo, 2 50
Woll's Handbook for Farmers and Dairymen.....	16mo, 1 50

ARCHITECTURE.

Baldwin's Steam Heating for Buildings.....	12mo, 2 50
Berg's Buildings and Structures of American Railroads.....	4to, 5 00
Birkmire's Planning and Construction of American Theatres.....	8vo, 3 00
Architectural Iron and Steel.....	8vo, 3 50
Compound Riveted Girders as Applied in Buildings.....	8vo, 2 00
Planning and Construction of High Office Buildings.....	8vo, 3 50
Skeleton Construction in Buildings.....	8vo, 3 00
Briggs's Modern American School Buildings.....	8vo, 4 00
Carpenter's Heating and Ventilating of Buildings.....	8vo, 4 00
Freitag's Architectural Engineering. 2d Edition, Rewritten.....	8vo, 3 50
Fireproofing of Steel Buildings.....	8vo, 2 50
French and Ives's Stereotomy.....	8vo, 2 50
Gerhard's Guide to Sanitary House-Inspection.....	16mo, 1 00
Theatre Fires and Panics.....	12mo 1 50

Holly's Carpenters' and Joiners' Handbook.....	18mo,	0	75
Johnson's Statics by Algebraic and Graphic Methods.....	8vo,	2	00
Kidder's Architect's and Builder's Pocket-book. (<i>Rewritten edition in preparation.</i>)			
Merrill's Stones for Building and Decoration.....	8vo,	5	00
Mouckton's Stair-building	4to,	4	00
Patton's Practical Treatise on Foundations.....	8vo,	5	00
Siebert and Biggin's Modern Stone-cutting and Masonry.....	8vo,	1	50
Snow's Principal Species of Wood.....	8vo,	3	50
Sondericker's Graphic Statics with Applications to Trusses, Beams, and Arches.			
	8vo,	2	00
Walt's Engineering and Architectural Jurisprudence.....	8vo,	6	00
	Sheep,	6	50
Law of Operations Preliminary to Construction in Engineering and Archi- tecture.....	8vo,	5	00
	Sheep,	5	50
Law of Contracts.....	8vo,	3	00
Woodbury's Fire Protection of Mills.....	8vo,	2	50
Worcester and Atkinson's Small Hospitals, Establishment and Maintenance, Suggestions for Hospital Architecture, with Plans for a Small Hospital.			
	12mo,	1	25
The World's Columbian Exposition of 1893.....	Large 4to,	1	00

ARMY AND NAVY.

Bernadon's Smokeless Powder, Nitro-cellulose, and the Theory of the Cellulose Molecule.....	12mo,	2	50
* Bruff's Text-book Ordnance and Gunnery.....	8vo,	6	00
Chase's Screw Propellers and Marine Propulsion.....	8vo,	3	00
Craig's Azimuth.....	4to,	3	50
Creore and Squire's Polarizing Photo-chronograph.....	8vo,	3	00
Cronkhitte's Gunnery for Non-commissioned Officers.....	24mo, morocco,	2	00
* Davis's Elements of Law.....	8vo,	2	50
* Treatise on the Military Law of United States.....	8vo,	7	00
	Sheep,	7	50
De Brack's Cavalry Outpost Duties. (Carr.).....	24mo morocco,	2	00
Dietz's Soldier's First Aid Handbook.....	16mo, morocco,	1	25
* Dredge's Modern French Artillery.....	4to, half morocco,	15	00
Durand's Resistance and Propulsion of Ships.....	8vo,	5	00
* Dyer's Handbook of Light Artillery.....	12mo,	3	00
Eissler's Modern High Explosives.....	8vo,	4	00
* Fieberger's Text-book on Field Fortification.....	Small 8vo,	2	00
Hamilton's The Gunner's Catechism.....	18mo,	1	00
* Hoff's Elementary Naval Tactics.....	8vo,	1	50
Ingalls's Handbook of Problems in Direct Fire.....	8vo,	4	00
* Ballistic Tables.....	8vo,	1	50
* Lyons's Treatise on Electromagnetic Phenomena. Vols. I. and II. 8vo, each,		6	00
* Mahan's Permanent Fortifications. (Mercur.).....	8vo, half morocco,	7	50
Manual for Courts-martial.....	16mo, morocco,	1	50
* Mercur's Attack of Fortified Places.....	12mo,	2	00
* Elements of the Art of War.....	8vo,	4	00
Metcalf's Cost of Manufactures—And the Administration of Workshops, Public and Private.....	8vo,	5	00
* Ordnance and Gunnery.....	12mo,	5	00
Murray's Infantry Drill Regulations.....	18mo, paper,	10	
* Phelps's Practical Marine Surveying.....	8vo,	2	50
Powell's Army Officer's Examiner.....	12mo,	4	00
St. Arpe's Art of Subsisting Armies in War.....	18mo, morocco,	1	50

* Walke's Lectures on Explosives.....	8vo,	4 00
* Wheeler's Siege Operations and Military Mining.....	8vo,	2 00
Winthrop's Abridgment of Military Law.....	12mo,	2 50
Woodhull's Notes on Military Hygiene.....	16mo,	1 50
Young's Simple Elements of Navigation.....	16mo, morocco,	1 00
Second Edition, Enlarged and Revised.....	16mo, morocco,	2 00

ASSAYING.

Fletcher's Practical Instructions in Quantitative Assaying with the Blowpipe.....	12mo, morocco,	1 50
Furman's Manual of Practical Assaying.....	8vo,	3 00
Miller's Manual of Assaying.....	12mo,	1 00
O'Driscoll's Notes on the Treatment of Gold Ores.....	8vo,	2 00
Ricketts and Miller's Notes on Assaying.....	8vo,	3 00
Ulke's Modern Electrolytic Copper Refining.....	8vo,	3 00
Wilson's Cyanide Processes.....	12mo,	1 50
Chlorination Process.....	12mo,	1 50

ASTRONOMY.

Comstock's Field Astronomy for Engineers.....	8vo,	2 50
Craig's Azimuth.....	4to,	3 50
Doolittle's Treatise on Practical Astronomy.....	8vo,	4 00
Gore's Elements of Geodesy.....	8vo,	2 50
Hayford's Text-book of Geodetic Astronomy.....	8vo,	3 00
Merriman's Elements of Precise Surveying and Geodesy.....	8vo,	2 50
* Michie and Harlow's Practical Astronomy.....	8vo,	3 00
* White's Elements of Theoretical and Descriptive Astronomy.....	12mo,	2 00

BOTANY.

Davenport's Statistical Methods, with Special Reference to Biological Variation.....	16mo, morocco,	1 25
Thomé and Bennett's Structural and Physiological Botany.....	16mo,	2 25
Westermaier's Compendium of General Botany. (Schneider.).....	8vo,	2 00

CHEMISTRY.

Adrian's Laboratory Calculations and Specific Gravity Tables.....	12mo,	1 25
Allen's Tables for Iron Analysis.....	8vo,	3 00
Arnold's Compendium of Chemistry. (Mandel.) (In preparation.).....		
Austen's Notes for Chemical Students.....	12mo,	1 50
Bernadou's Smokeless Powder.—Nitro-cellulose, and Theory of the Cellulose Molecule.....	12mo,	2 50
Bolton's Quantitative Analysis.....	8vo,	1 50
* Browning's Introduction to the Rarer Elements.....	8vo,	1 50
Brush and Penfield's Manual of Determinative Mineralogy.....	8vo,	4 00
Classen's Quantitative Chemical Analysis by Electrolysis. (Boltwood.).....	8vo,	3 00
Cohn's Indicators and Test-papers.....	12mo,	2 00
Tests and Reagents.....	8vo,	3 00
Copeland's Manual of Bacteriology. (In preparation.).....		
Craft's Short Course in Qualitative Chemical Analysis. (Schaeffer.).....	12mo,	1 50
Drechsel's Chemical Reactions. (Merrill.).....	12mo,	1 25
Duhem's Thermodynamics and Chemistry. (Burgess.).....	8vo,	4 00
Eissler's Modern High Explosives.....	8vo,	4 00

Edmont's Enzymes and their Applications. (Prescott.)	8vo,	3 00	
Erdmann's Introduction to Chemical Preparations. (Dunlap.)	12mo,	1 25	
Fletcher's Practical Instructions in Quantitative Assaying with the Blowpipe.	12mo, morocco,	1 50	
Fowler's Sewage Works Analyses.	12mo,	2 00	
Fresenius's Manual of Qualitative Chemical Analysis. (Wells.)	8vo,	5 00	
Manual of Qualitative Chemical Analysis. Part I. Descriptive. (Wells.)	8vo,	3 00	
System of Instruction in Quantitative Chemical Analysis. (Cohn.)	2 vols. (Shortly.)		
Fuertes's Water and Public Health.	12mo,	1 50	
Ferman's Manual of Practical Assaying.	8vo,	3 00	
Gill's Gas and Fuel Analysis for Engineers.	12mo,	1 25	
Grottenfelt's Principles of Modern Dairy Practice. (Woll.)	12mo,	2 00	
Hammarssten's Text-book of Physiological Chemistry. (Mandel.)	8vo,	4 00	
Helm's Principles of Mathematical Chemistry. (Morgan.)	12mo,	1 50	
Hinds's Inorganic Chemistry.	8vo,	3 00	
* Laboratory Manual for Students	12mo,	75	
Mohrman's Text-book of Inorganic Chemistry. (Cooper.)	8vo,	2 50	
Text-book of Organic Chemistry. (Walker and Mott.)	8vo,	2 50	
Hopkins's Oil-chemists' Handbook.	8vo,	3 00	
Jackson's Directions for Laboratory Work in Physiological Chemistry.	8vo,	1 00	
Keep's Cast Iron.	8vo,	2 50	
Ladd's Manual of Quantitative Chemical Analysis.	12mo,	1 00	
Landauer's Spectrum Analysis. (Tingle.)	8vo,	3 00	
Lassar-Cohn's Practical Urinary Analysis. (Lorenz.)	12mo,	1 00	
Leach's The Inspection and Analysis of Food with Special Reference to State Control. (In preparation.)			
Lbb's Electrolysis and Electroynthesis of Organic Compounds. (Lorenz.)	12mo,	1 00	
Mandel's Handbook for Bio-chemical Laboratory.	12mo,	1 50	
* Martin's Laboratory Guide to Qualitative Analysis with the Blowpipe.	12mo,	6c	
Mason's Water-supply. (Considered Principally from a Sanitary Standpoint.)	3d Edition, Rewritten.	8vo,	4 00
* Examination of Water. (Chemical and Bacteriological.)	12mo,	1 25	
Meyer's Determination of Radicles in Carbon Compounds. (Tingle.)	12mo,	1 00	
Miller's Manual of Assaying.	12mo,	1 00	
Mixter's Elementary Text-book of Chemistry.	12mo,	1 50	
Morgan's Outline of Theory of Solution and its Results.	12mo,	1 00	
Elements of Physical Chemistry.	12mo,	2 00	
Nichols's Water-supply. (Considered mainly from a Chemical and Sanitary Standpoint, 1883.)	8vo,	2 50	
O'Brine's Laboratory Guide in Chemical Analysis.	8vo,	2 00	
O'Driscoll's Notes on the Treatment of Gold Ores.	8vo,	2 00	
Ost and Kolbeck's Text-book of Chemical Technology. (Lorenz—Bozart.)	(In preparation.)		
* Penfield's Notes on Determinative Mineralogy and Record of Mineral Tests.	8vo, paper,	50	
Pictet's The Alkaloids and their Chemical Constitution. (Biddle.) (In preparation.)			
Pinner's Introduction to Organic Chemistry. (Austen.)	12mo,	1 50	
Poole's Calorific Power of Fuels.	8vo,	3 00	
* Reising's Guide to Piece-dyeing.	8vo,	25 00	
Richards and Woodman's Air, Water, and Food from a Sanitary Standpoint.	8vo,	2 00	
Richards's Cost of Living as Modified by Sanitary Science.	12mo,	1 00	
Cost of Food a Study in Dietsaries.	12mo,	1 00	
* Richards and Williams's The Dietary Computer.	8vo,	1 50	
Ricketts and Russell's Skeleton Notes upon Inorganic Chemistry. (Part I.—Non-metallic Elements.)	8vo, morocco,	75	

Ricketts and Miller's Notes on Assaying.....	8vo,	3 00
Rideal's Sewage and the Bacterial Purification of Sewage.....	8vo,	3 50
Ruddiman's Incompatibilities in Prescriptions.....	8vo,	2 00
Salkowski's Physiological and Pathological Chemistry. (Orndorff.) (Shortly.)		
Schimpf's Text-book of Volumetric Analysis.....	12mo,	2 50
Essentials of Volumetric Analysis.....	12mo,	1 25
Spencer's Handbook for Chemists of Beet-sugar Houses.....	16mo, morocco,	3 00
Handbook for Sugar Manufacturers and their Chemists.....	16mo, morocco,	2 00
Stockbridge's Rocks and Soils.....	8vo,	2 50
* Tillman's Elementary Lessons in Heat.....	8vo,	1 50
* Descriptive General Chemistry.....	8vo	3 00
Treadwell's Qualitative Analysis. (Hall).....	8vo,	3 00
Turneure and Russell's Public Water-supplies.....	8vo,	5 00
Van Deventer's Physical Chemistry for Beginners. (Boltwood.).....	12mo,	1 50
* Walke's Lectures on Explosives.....	8vo,	4 00
Wells's Laboratory Guide in Qualitative Chemical Analysis.....	8vo,	1 50
Short Course in Inorganic Qualitative Chemical Analysis for Engineering Students.....	12mo,	1 50
Whipple's Microscopy of Drinking-water.....	8vo,	3 50
Wiechmann's Sugar Analysis.....	Small 8vo,	2 50
Wilson's Cyanide Processes.....	12mo,	1 50
Chlorination Process.....	12mo,	1 50
Wulling's Elementary Course in Inorganic Pharmaceutical and Medical Chem- istry.....	12mo,	2 00

CIVIL ENGINEERING.

BRIDGES AND ROOFS. HYDRAULICS. MATERIALS OF ENGINEERING. RAILWAY ENGINEERING.

Baker's Engineers' Surveying Instruments.....	12mo,	3 00
Bixby's Graphical Computing Table.....	Paper 19½ X 24½ inches,	25
** Burr's Ancient and Modern Engineering and the Isthmian Canal. (Postage, 27 cents additional.).....	8vo, net,	3 50
Comstock's Field Astronomy for Engineers.....	8vo,	2 50
Davis's Elevation and Stadia Tables.....	8vo,	1 00
Elliott's Engineering for Land Drainage.....	12mo,	1 50
Practical Farm Drainage.....	12mo,	1 00
Folwell's Sewerage. (Designing and Maintenance.).....	8vo,	3 00
Freitag's Architectural Engineering. 2d Edition, Rewritten.....	8vo,	3 50
French and Ives's Stereotomy.....	8vo,	2 50
Goodhue's Municipal Improvements.....	12mo,	1 75
Goodrich's Economic Disposal of Towns' Refuse.....	8vo,	3 50
Gore's Elements of Geodesy.....	8vo,	2 50
Hayford's Text-book of Geodetic Astronomy.....	8vo,	3 00
Howe's Retaining Walls for Earth.....	12mo,	1 25
Johnson's Theory and Practice of Surveying.....	Small 8vo,	4 00
Statics by Algebraic and Graphic Methods.....	8vo,	2 00
Kiersted's Sewage Disposal.....	12mo,	1 25
Laplace's Philosophical Essay on Probabilities. (Truscott and Emory.).....	12mo,	2 00
Mahan's Treatise on Civil Engineering. (1873) (Wood.).....	8vo,	5 00
* Descriptive Geometry.....	8vo,	1 50
Merriman's Elements of Precise Surveying and Geodesy.....	8vo,	2 50
Elements of Sanitary Engineering.....	8vo,	2 00
Merriman and Brooks's Handbook for Surveyors.....	16mo, morocco,	2 00
Nugent's Plane Surveying.....	8vo,	3 50
Ogden's Sewer Design.....	12mo,	2 00
Patton's Treatise on Civil Engineering.....	8vo half leather,	7 50

Reed's Topographical Drawing and Sketching.....	4to,	5 00
Rideal's Sewage and the Bacterial Purification of Sewage.....	8vo,	3 50
Seibert and Biggin's Modern Stone-cutting and Masonry.....	8vo,	1 50
Smith's Manual of Topographical Drawing. (McMillan.).....	8vo,	2 50
Sendericker's Graphic Statics, with Applications to Trusses, Beams, and Arches.....	8vo,	2 00
* Trautwine's Civil Engineer's Pocket-book.....	16mo, morocco,	5 00
Walt's Engineering and Architectural Jurisprudence.....	8vo,	6 00
	Sheep,	6 50
Law of Operations Preliminary to Construction in Engineering and Archi- tecture.....	8vo,	5 00
	Sheep,	5 50
Law of Contracts.....	8vo,	3 00
Warren's Stereotomy—Problems in Stone-cutting.....	8vo,	2 50
Webb's Problems in the Use and Adjustment of Engineering Instruments.....	16mo, morocco,	1 25
* Wheeler's Elementary Course of Civil Engineering.....	8vo,	4 00
Wilson's Topographic Surveying.....	8vo,	3 50

BRIDGES AND ROOFS.

Boller's Practical Treatise on the Construction of Iron Highway Bridges.....	8vo,	2 00
* Thames River Bridge.....	4to, paper,	5 00
Burr's Course on the Stresses in Bridges and Roof Trusses, Arched Ribs, and Suspension Bridges.....	8vo,	3 50
Du Bois's Mechanics of Engineering. Vol. II.....	Small 4to,	10 00
Foster's Treatise on Wooden Trestle Bridges.....	4to,	5 00
Fowler's Coffier-dam Process for Piers.....	8vo,	2 50
Greene's Roof Trusses.....	8vo,	1 25
Bridge Trusses.....	8vo,	2 50
Arches in Wood, Iron, and Stone.....	8vo,	2 50
Howe's Treatise on Arches.....	8vo,	4 00
Design of Simple Roof-trusses in Wood and Steel.....	8vo,	2 00
Johnson, Bryan, and Turneure's Theory and Practice in the Designing of Modern Framed Structures.....	Small 4to,	10 00
Merriman and Jacoby's Text-book on Roofs and Bridges:		
Part I.—Stresses in Simple Trusses.....	8vo,	2 50
Part II.—Graphic Statics.....	8vo,	2 50
Part III.—Bridge Design. 4th Edition, Rewritten.....	8vo,	2 50
Part IV.—Higher Structures.....	8vo,	2 50
Morison's Memphis Bridge.....	4to,	10 00
Waddell's De Pontibus, a Pocket-book for Bridge Engineers.....	16mo, morocco,	3 00
Specifications for Steel Bridges.....	12mo,	1 25
Wood's Treatise on the Theory of the Construction of Bridges and Roofs.....	8vo,	2 00
Wright's Designing of Draw-spans:		
Part I. —Plate-girder Draws.....	8vo,	2 50
Part II.—Riveted-truss and Pin-connected Long-span Draws.....	8vo,	2 50
Two parts in one volume.....	8vo,	3 50

HYDRAULICS.

Bazin's Experiments upon the Contraction of the Liquid Vein Issuing from an Orifice. (Trautwine.).....	8vo,	2 00
Bovey's Treatise on Hydraulics.....	8vo,	5 00
Church's Mechanics of Engineering.....	8vo,	6 00
Diagrams of Mean Velocity of Water in Open Channels.....	paper,	1 50

Coffin's Graphical Solution of Hydraulic Problems.....	16mo, morocco,	2 50
Flather's Dynamometers, and the Measurement of Power.....	12mo,	3 00
Folwell's Water-supply Engineering.....	8vo,	4 00
Frizell's Water-power.....	8vo,	5 00
Fuertes's Water and Public Health.....	12mo,	1 50
Water-filtration Works.....	12mo,	2 50
Ganguillet and Kutter's General Formula for the Uniform Flow of Water in Rivers and Other Channels. (Hering and Trautwine.).....	8vo,	4 00
Hazen's Filtration of Public Water-supply.....	8vo,	3 00
Hazlehurst's Towers and Tanks for Water-works.....	8vo,	2 50
Herschel's 115 Experiments on the Carrying Capacity of Large, Riveted, Metal Conduits.....	8vo,	2 00
Mason's Water-supply. (Considered Principally from a Sanitary Stand-point.) 3d Edition, Rewritten.....	8vo,	4 00
Merriman's Treatise on Hydraulics. 9th Edition, Rewritten.....	8vo,	5 00
* Michie's Elements of Analytical Mechanics.....	8vo,	4 00
Schuyler's Reservoirs for Irrigation, Water-power, and Domestic Water-supply.....	Large 8vo,	5 00
** Thomas and Watt's Improvement of Rivers. (Post., 44 c. additional),	4to,	6 00
Turneure and Russell's Public Water-supplies.....	8vo,	5 00
Wegmann's Design and Construction of Dams.....	4to,	5 00
Water-supply of the City of New York from 1658 to 1895.....	4to,	10 00
Weisbach's Hydraulics and Hydraulic Motors. (Du Bois.).....	8vo,	5 00
Wilson's Manual of Irrigation Engineering.....	Small 8vo,	4 00
Wolff's Windmill as a Prime Mover.....	8vo,	3 00
Wood's Turbines.....	8vo,	2 50
Elements of Analytical Mechanics.....	8vo,	3 00

MATERIALS OF ENGINEERING.

Baker's Treatise on Masonry Construction.....	8vo,	5 00
Roads and Pavements.....	8vo,	5 00
Black's United States Public Works.....	Oblong 4to,	5 00
Bover's Strength of Materials and Theory of Structures.....	8vo,	7 50
Burr's Elasticity and Resistance of the Materials of Engineering. 6th Edition, Rewritten.....	8vo,	7 50
Byrne's Highway Construction.....	8vo,	5 00
Inspection of the Materials and Workmanship Employed in Construction.....	16mo,	3 00
Church's Mechanics of Engineering.....	8vo,	6 00
Du Bois's Mechanics of Engineering. Vol. I.....	Small 4to,	7 50
Johnson's Materials of Construction.....	Large 8vo,	6 00
Keep's Cast Iron.....	8vo,	2 50
Lanza's Applied Mechanics.....	8vo,	7 50
Martens's Handbook on Testing Materials. (Henning.) 2 vols.....	8vo,	7 50
Merrill's Stones for Building and Decoration.....	8vo,	5 00
Merriman's Text-book on the Mechanics of Materials.....	8vo,	4 00
Strength of Materials.....	12mo,	1 00
Metcalf's Steel. A Manual for Steel-users.....	12mo,	2 00
Patton's Practical Treatise on Foundations.....	8vo,	5 00
Rockwell's Roads and Pavements in France.....	12mo,	1 25
Smith's Wire: Its Use and Manufacture.....	Small 4to,	3 00
Materials of Machines.....	12mo,	1 00
Snow's Principal Species of Wood.....	8vo,	3 50
Spalding's Hydraulic Cement.....	12mo,	2 00
Text-book on Roads and Pavements.....	12mo,	2 00

Thurston's Materials of Engineering. 3 Parts.....	8vo,	8 00
Part I.—Non-metallic Materials of Engineering and Metallurgy.....	8vo,	2 00
Part II.—Iron and Steel.....	8vo,	3 50
Part III.—A Treatise on Brasses, Bronzes, and Other Alloys and their Constituents.....	8vo,	2 50
Thurston's Text-book of the Materials of Construction.....	8vo,	5 00
Tilmon's Street Pavements and Paving Materials.....	8vo,	4 00
Waddell's De Pontibus. (A Pocket-book for Bridge Engineers.)..	16mo, mor.,	3 00
Specifications for Steel Bridges.....	12mo,	1 25
Wood's Treatise on the Resistance of Materials, and an Appendix on the Pres- ervation of Timber.....	8vo,	2 00
Elements of Analytical Mechanics.....	8vo,	3 00
Wood's Rustless Coatings. (Shortly.)		

RAILWAY ENGINEERING.

Andrews's Handbook for Street Railway Engineers. 3x5 inches.	morocco,	1 25
Berg's Buildings and Structures of American Railroads.	4to,	5 00
Brooks's Handbook of Street Railroad Location.	16mo. morocco,	1 50
Butts's Civil Engineer's Field-book.	16mo, morocco,	2 50
Crandall's Transition Curve.	16mo, morocco,	1 50
Railway and Other Earthwork Tables. 8vo, 1 50		
Dawson's "Engineering" and Electric Traction Pocket-book. 16mo, morocco,		5 00
Dredge's History of the Pennsylvania Railroad: (1879).	Paper,	5 00
* Drinker's Tunneling, Explosive Compounds, and Rock Drills, 4to, half mor.,		25 00
Fisher's Table of Cubic Yards.	Cardboard	25
Godwin's Railroad Engineers' Field-book and Explorers' Guide.	16mo, mor.,	2 50
Howard's Transition Curve Field-book.	16mo, morocco,	1 50
Hudson's Tables for Calculating the Cubic Contents of Excavations and Em- bankments.	8vo,	1 00
Molitor and Beard's Manual for Resident Engineers.	16mo,	1 00
Nagle's Field Manual for Railroad Engineers.	16mo, morocco,	3 00
Philbrick's Field Manual for Engineers.	16mo, morocco,	3 00
Pratt and Alden's Street-railway Road-bed.	8vo,	2 00
Searles's Field Engineering.	16mo, morocco,	3 00
Railroad Spiral.	16mo, morocco,	1 50
Taylor's Prismoidal Formulæ and Earthwork.	8vo,	1 50
* Trautwine's Method of Calculating the Cubic Contents of Excavations and Embankments by the Aid of Diagrams.	8vo,	2 00
The Field Practice of Laying Out Circular Curves for Railroads.	12mo, morocco,	2 50
* Cross-section Sheet.	Paper,	25
Webb's Railroad Construction. 2d Edition, Rewritten.	16mo. morocco,	5 00
Wellington's Economic Theory of the Location of Railways.	Small 8vo,	5 00

DRAWING.

Barr's Kinematics of Machinery.....	8vo,	2 50
* Bartlett's Mechanical Drawing.....	8vo,	3 00
* " " Abridged Ed.....	8vo,	1 50
Coolidge's Manual of Drawing.....	8vo, paper,	1 00
Durley's Kinematics of Machines.....	8vo,	4 00
Hill's Text-book on Shades and Shadows, and Perspective.....	8vo,	2 00
Jones's Machine Design:		
Part I.—Kinematics of Machinery.....	8vo,	1 50
Part II.—Form, Strength, and Proportions of Parts.....	8vo,	3 00

MacCord's Elements of Descriptive Geometry.....	8vo,	3 00
Kinematics; or, Practical Mechanism.....	8vo,	5 00
Mechanical Drawing.....	4to,	4 00
Velocity Diagrams.....	8vo,	1 50
* Mahan's Descriptive Geometry and Stone-cutting.....	8vo,	1 50
Industrial Drawing. (Thompson.).....	8vo,	3 50
Reed's Topographical Drawing and Sketching.....	4to,	5 00
Reid's Course in Mechanical Drawing.....	8vo,	2 00
Text-book of Mechanical Drawing and Elementary Machine Design.....	8vo,	3 00
Robinson's Principles of Mechanism.....	8vo,	3 00
Smith's Manual of Topographical Drawing. (McMillan.).....	8vo,	2 50
Warren's Elements of Plane and Solid Free-hand Geometrical Drawing.....	12mo,	1 00
Drafting Instruments and Operations.....	12mo,	1 25
Manual of Elementary Projection Drawing.....	12mo,	1 50
Manual of Elementary Problems in the Linear Perspective of Form and Shadow.....	12mo,	1 00
Plane Problems in Elementary Geometry.....	12mo,	1 25
Primary Geometry.....	12mo,	75
Elements of Descriptive Geometry, Shadows, and Perspective.....	8vo,	3 50
General Problems of Shades and Shadows.....	8vo,	3 00
Elements of Machine Construction and Drawing.....	8vo,	7 50
Problems, Theorems, and Examples in Descriptive Geometry.....	8vo,	2 50
Weissbach's Kinematics and the Power of Transmission. (Hermann and Klein.).....	8vo,	5 00
Whipple's Practical Instruction in the Art of Letter Engraving.....	12mo,	2 00
Wilson's Topographic Surveying.....	8vo,	3 50
Free-hand Perspective.....	8vo,	2 50
Free-hand Lettering.....	8vo,	1 00
Wolf's Elementary Course in Descriptive Geometry.....	Large 8vo,	3 00

ELECTRICITY AND PHYSICS.

Anthony and Brackett's Text-book of Physics. (Magie.).....	Small 8vo,	3 00
Anthony's Lecture-notes on the Theory of Electrical Measurements.....	12mo,	1 00
Benjamin's History of Electricity.....	8vo,	3 00
Voltaic Cell.....	8vo,	3 00
Claassen's Quantitative Chemical Analysis by Electrolysis. (Boltwood.).....	8vo,	3 00
Crehore and Squier's Polarizing Photo-chronograph.....	8vo,	3 00
Dawson's "Engineering" and Electric Traction Pocket-book.....	16mo, morocco,	5 00
Delezailek's Theory of the Lead Accumulator. (Storage Battery.) (<i>Shortly.</i>) (Von Ende.).....		
Duhem's Thermodynamics and Chemistry. (Burgess.).....	8vo,	4 00
Flather's Dynamos, and the Measurement of Power.....	12mo,	3 00
Gilbert's De Magnete. (Mottelay.).....	8vo,	2 50
Hanchett's Alternating Currents Explained. (<i>Shortly.</i>).....		
Holman's Precision of Measurements.....	8vo,	2 00
Telescopic Mirror-scale Method, Adjustments, and Tests.....	Large 8vo,	75
Landauer's Spectrum Analysis. (Tingle.).....	8vo,	3 00
Le Chatelier's High-temperature Measurements. (Boudouard—Burgess.).....	12mo,	3 00
Löb's Electrolysis and Electrosynthesis of Organic Compounds. (Lorenz.).....	12mo,	1 00
* Lyons's Treatise on Electromagnetic Phenomena. Vols. I. and II. 8vo, each.....		6 00
* Michie. Elements of Wave Motion Relating to Sound and Light.....	8vo,	4 00
Niandet's Elementary Treatise on Electric Batteries. (Fishback.).....	12mo,	2 50
* Parshall and Hobart's Electric Generators.....	Small 4to, half morocco,	10 00
* Rosenberg's Electrical Engineering. (Haldane Gee—Kinzbrunner.).....	8vo,	1 50
Ryan, Norris, and Hoxie's Electrical Machinery. Vol. I.....	8vo,	2 50
Thurston's Stationary Steam-engines.....	8vo,	2 50
* Tillman's Elementary Lessons in Heat.....	8vo,	1 50

Tory and Pitcher's Manual of Laboratory Physics	Small 8vo, 2 00
Ulke's Modern Electrolytic Copper Refining	8vo, 3 00

LAW.

* Davis's Elements of Law	8vo, 2 50
* Treatise on the Military Law of United States	8vo, 7 00
*	Sheep, 7 50
Manual for Courts-martial	16mo, morocco, 1 50
Wait's Engineering and Architectural Jurisprudence	8vo, 6 00
.....	Sheep, 6 50
Law of Operations Preliminary to Construction in Engineering and Archi- tecture	8vo, 5 00
.....	Sheep, 5 50
Law of Contracts	8vo, 3 00
Winthrop's Abridgment of Military Law	12mo, 2 50

MANUFACTURES.

Barnadou's Smokeless Powder—Nitro-cellulose and Theory of the Cellulose Molecule	12mo, 2 50
Bolland's Iron Founder	12mo, 2 50
"The Iron Founder," Supplement	12mo, 2 50
Encyclopedia of Founding and Dictionary of Foundry Terms Used in the Practice of Moulding	12mo, 3 00
Eisler's Modern High Explosives	8vo, 4 00
Effront's Enzymes and their Applications. (Prescott.)	8vo, 3 00
Fitzgerald's Boston Machinist	18mo, 1 00
Ford's Boiler Making for Boiler Makers	18mo, 1 00
Hopkins's Oil-chemists' Handbook	8vo, 3 00
Keep's Cast Iron	8vo, 2 50
Leach's The Inspection and Analysis of Food with Special Reference to State Control. (<i>In preparation.</i>)	12mo, 2 00
Metcalf's Steel. A Manual for Steel-users	12mo, 2 00
Metcalf's Cost of Manufactures—And the Administration of Workshops, Public and Private	8vo, 5 00
Meyer's Modern Locomotive Construction	4to, 10 00
* Reisig's Guide to Piece-dyeing	8vo, 25 00
Smith's Press-working of Metals	8vo, 3 00
Wire: Its Use and Manufacture	Small 4to, 3 00
Spalding's Hydraulic Cement	12mo, 2 00
Spencer's Handbook for Chemists of Beet-sugar Houses	16mo, morocco, 3 00
Handbook for Sugar Manufacturers and their Chemists	16mo, morocco, 2 00
Thurston's Manual of Steam-boilers, their Designs, Construction and Opera- tion	8vo, 5 00
* Walke's Lectures on Explosives	8vo, 4 00
West's American Foundry Practice	12mo, 2 50
Moulder's Text-book	12mo, 2 50
Wiechmann's Sugar Analysis	Small 8vo, 2 50
Wolf's Windmill as a Prime Mover	8vo, 3 00
Woodbury's Fire Protection of Mills	8vo, 2 50

MATHEMATICS.

Baker's Elliptic Functions	8vo, 1 50
* Bass's Elements of Differential Calculus	12mo, 4 00
Briggs's Elements of Plane Analytic Geometry	12mo, 1 00

Compton's Manual of Logarithmic Computations.....	12mo,	1 50
Davis's Introduction to the Logic of Algebra.....	8vo,	1 50
* Dickson's College Algebra	Large 12mo,	1 50
* Introduction to the Theory of Algebraic Equations	Large 12mo,	1 25
Halsted's Elements of Geometry	8vo,	1 75
Elementary Synthetic Geometry.....	8vo,	1 50
Rational Geometry. (<i>Shortly.</i>)		
* Johnson's Three-place Logarithmic Tables: Vest-pocket size.....	paper,	15
	100 copies for	5 00
* Mounted on heavy cardboard, 8X10 inches,		25
	10 copies for	2 00
Elementary Treatise on the Integral Calculus.....	Small 8vo,	1 50
Curve Tracing in Cartesian Co-ordinates.....	12mo,	1 00
Treatise on Ordinary and Partial Differential Equations.....	Small 8vo,	3 50
Theory of Errors and the Method of Least Squares.....	12mo,	1 50
* Theoretical Mechanics.....	12mo,	3 00
Laplace's Philosophical Essay on Probabilities. (Truscott and Emory.)	12mo,	2 00
* Ludlow and Bass. Elements of Trigonometry and Logarithmic and Other Tables.....	8vo,	3 00
Trigonometry and Tables published separately.....	Each,	2 00
Maurer's Technical Mechanics.....	8vo,	4 00
Merriman and Woodward's Higher Mathematics	8vo,	5 00
Merriman's Method of Least Squares	8vo,	2 00
Rice and Johnson's Elementary Treatise on the Differential Calculus.Sm.,	8vo,	3 00
Differential and Integral Calculus. 2 vols. in one.....	Small 8vo,	2 50
Wood's Elements of Co-ordinate Geometry.....	8vo,	2 00
Trigonometry: Analytical, Plane, and Spherical.....	12mo,	1 00

MECHANICAL ENGINEERING.

MATERIALS OF ENGINEERING, STEAM-ENGINES AND BOILERS.

Baldwin's Steam Heating for Buildings.....	12mo,	2 50
Barr's Kinematics of Machinery.....	8vo,	2 50
* Bartlett's Mechanical Drawing	8vo,	3 00
* " " " Abridged Ed.....	8vo,	1 50
Benjamin's Wrinkles and Recipes.....	12mo,	2 00
Carpenter's Experimental Engineering.....	8vo,	6 00
Heating and Ventilating Buildings.....	8vo,	4 00
Cary's Smoke Suppression in Plants using Bituminous Coal. (<i>In preparation.</i>)		
Clerk's Gas and Oil Engine.....	Small 8vo,	4 00
Coolidge's Manual of Drawing.....	8vo, paper,	1 00
Cromwell's Treatise on Toothed Gearing.....	12mo,	1 50
Treatise on Belts and Puleys.....	12mo,	1 50
Durley's Kinematics of Machines.....	8vo,	4 00
Flather's Dynamometers and the Measurement of Power.....	12mo,	3 00
Rope Driving.....	12mo,	2 00
Gill's Gas and Fuel Analysis for Engineers.....	12mo,	1 25
Hall's Car Lubrication.....	12mo,	1 00
Hutton's The Gas Engine.....	8vo,	5 00
Jones's Machine Design:		
Part I.—Kinematics of Machinery	8vo,	1 50
Part II.—Form, Strength, and Proportions of Parts.....	8vo,	3 00
Kent's Mechanical Engineer's Pocket-book.....	16mo, morocco,	5 00
Kerr's Power and Power Transmission.....	8vo,	2 00
MacCord's Kinematics; or, Practical Mechanism.....	8vo,	5 00
Mechanical Drawing.....	4to,	4 00
Velocity Diagrams.....	8vo,	1 50

Mahan's Industrial Drawing. (Thompson.)	8vo,	3 50
Poole's Calorific Power of Fuels	8vo,	3 00
Reid's Course in Mechanical Drawing	8vo,	2 00
Text-book of Mechanical Drawing and Elementary Machine Design	8vo,	3 00
Richards's Compressed Air	12mo,	1 50
Robinson's Principles of Mechanism	8vo,	3 00
Smith's Press-working of Metals	8vo,	3 00
Thurston's Treatise on Friction and Lost Work in Machinery and Mill Work	8vo,	3 00
Animal as a Machine and Prime Motor, and the Laws of Energetics	12mo,	1 00
Warren's Elements of Machine Construction and Drawing	8vo,	7 50
Weisbach's Kinematics and the Power of Transmission. Herrmann—Klein.)	8vo,	5 00
Machinery of Transmission and Governors. (Herrmann—Klein.)	8vo,	5 00
Hydraulics and Hydraulic Motors. (Du Bois.)	8vo,	5 00
Wolff's Windmill as a Prime Mover	8vo,	3 00
Wood's Turbines	8vo,	2 50

MATERIALS OF ENGINEERING.

Bovey's Strength of Materials and Theory of Structures	8vo,	7 50
Burr's Elasticity and Resistance of the Materials of Engineering. 6th Edition, Reset.	8vo,	7 50
Church's Mechanics of Engineering	8vo,	6 00
Johnson's Materials of Construction	Large 8vo,	6 00
Keep's Cast Iron	8vo,	2 50
Lanza's Applied Mechanics	8vo,	7 50
Martens's Handbook on Testing Materials. (Henning.)	8vo,	7 50
Merriman's Text-book on the Mechanics of Materials	8vo,	4 00
Strength of Materials	12mo,	1 00
Metcalf's Steel. A Manual for Steel-users	12mo,	2 00
Smith's Wire: Its Use and Manufacture	Small 4to,	3 00
Materials of Machines	12mo,	1 00
Thurston's Materials of Engineering	3 vols, 8vo,	8 00
Part II.—Iron and Steel	8vo,	3 50
Part III.—A Treatise on Brasses, Bronzes, and Other Alloys and their Constituents	8vo,	2 50
Text-book of the Materials of Construction	8vo,	5 00
Wood's Treatise on the Resistance of Materials and an Appendix on the Preservation of Timber	8vo,	2 00
Elements of Analytical Mechanics	8vo,	3 00
Wood's Rustless Coatings. (Shortly.)		

STEAM-ENGINES AND BOILERS.

Carnot's Reflections on the Motive Power of Heat. (Thurston.)	12mo,	1 50
Dawson's "Engineering" and Electric Traction Pocket-book	16mo, mor,	5 00
Ford's Boiler Making for Boiler Makers	18mo,	1 00
Goss's Locomotive Sparks	8vo,	2 00
Hemenway's Indicator Practice and Steam-engine Economy	12mo,	2 00
Hutton's Mechanical Engineering of Power Plants	8vo,	5 00
Heat and Heat-engines	8vo,	5 00
Kent's Steam-boiler Economy	8vo,	4 00
Kneass's Practice and Theory of the Injector	8vo,	1 50
MacCord's Slide-valves	8vo,	2 00
Meyer's Modern Locomotive Construction	4to,	10 00

Peabody's Manual of the Steam-engine Indicator	12mo,	1	50
Tables of the Properties of Saturated Steam and Other Vapors.....	8vo,	1	00
Thermodynamics of the Steam-engine and Other Heat-engines.....	8vo,	5	00
Valve-gears for Steam-engines.....	8vo,	2	50
Peabody and Miller's Steam-boilers	8vo,	4	00
Pray's Twenty Years with the Indicator	Large 8vo,	2	50
Puplin's Thermodynamics of Reversible Cycles in Gases and Saturated Vapors. (Osterberg.)	12mo,	1	25
Reagan's Locomotives: Simple, Compound, and Electric.....	12mo,	2	50
Rontgen's Principles of Thermodynamics. (Du Bois.)	8vo,	5	00
Sinclair's Locomotive Engine Running and Management.....	12mo,	2	00
Smart's Handbook of Engineering Laboratory Practice	12mo,	2	50
Snow's Steam-boiler Practice.....	8vo,	3	00
Spangler's Valve-gears.....	8vo,	2	50
Notes on Thermodynamics.....	12mo,	1	00
Spangler, Greene, and Marshall's Elements of Steam-engineing.....	8vo,	3	00
Thurston's Handy Tables.....	8vo,	1	50
Manual of the Steam-engine.....	2 vols. 8vo,	10	00
Part I.—History, Structure, and Theory.....	8vo,	6	00
Part II.—Design, Construction, and Operation.....	8vo,	6	00
Handbook of Engine and Boiler Trials, and the Use of the Indicator and the Prony Brake.....	8vo,	5	00
Stationary Steam-engines.....	8vo,	2	50
Steam-boiler Explosions in Theory and in Practice.....	12mo	1	50
Manual of Steam-boilers, Their Designs, Construction, and Operation.....	8vo,	5	00
Weisbach's Heat, Steam, and Steam-engines. (Du Bois.).....	8vo,	5	00
Whitham's Steam-engine Design.....	8vo,	5	00
Wilson's Treatise on Steam-boilers. (Flather.).....	16mo,	2	50
Wood's Thermodynamics. Heat Motors, and Refrigerating Machines.....	8vo,	4	00

MECHANICS AND MACHINERY.

Barr's Kinematics of Machinery.....	8vo,	2	50
Bovey's Strength of Materials and Theory of Structures.....	8vo,	7	50
Chase's The Art of Pattern-making.....	12mo,	2	50
Chordal.—Extracts from Letters	12mo,	2	00
Church's Mechanics of Engineering.....	8vo,	6	00
Notes and Examples in Mechanics.....	8vo,	2	00
Compton's First Lessons in Metal-working.....	12mo,	1	50
Compton and De Groodt's The Speed Lathe	12mo,	1	50
Cromwell's Treatise on Toothed Gearing.....	12mo,	1	50
Treatise on Belts and Pulleys.....	12mo,	1	50
Dana's Text-book of Elementary Mechanics for the Use of Colleges and Schools.....	12mo,	1	50
Dingey's Machinery Pattern Making.....	12mo,	2	00
Dredge's Record of the Transportation Exhibits Building of the World's Columbian Exposition of 1893	4to, half morocco,	5	00
Du Bois's Elementary Principles of Mechanics:			
Vol. I.—Kinematics.....	8vo,	3	50
Vol. II.—Statics.....	8vo,	4	00
Vol. III.—Kinetics.....	8vo,	3	50
Mechanics of Engineering. Vol. I.....	Small 4to,	7	50
Vol. II.....	Small 4to,	10	00
Durley's Kinematics of Machines.....	8vo,	4	00
Fitzgerald's Boston Machinist.....	16mo,	1	00
Flather's Dynamometers, and the Measurement of Power.....	12mo,	3	00
Rope Driving.....	12mo,	2	00
Goss's Locomotive Sparks.....	8vo,	2	00

Hall's Car Lubrication.....	12mo,	1 00
Holly's Art of Saw Filing.....	18mo	75
* Johnson's Theoretical Mechanics.....	12mo,	3 00
Statics by Graphic and Algebraic Methods.....	8vo,	2 00
Jones's Machine Design:		
Part I.—Kinematics of Machinery.....	8vo,	1 50
Part II.—Form, Strength, and Proportions of Parts.....	8vo,	3 00
Kerr's Power and Power Transmission.....	8vo,	2 00
Lanza's Applied Mechanics.....	8vo,	7 50
MacCord's Kinematics; or, Practical Mechanism.....	8vo,	5 00
Velocity Diagrams.....	8vo,	1 50
Maurer's Technical Mechanics.....	8vo,	4 00
Merriman's Text-book on the Mechanics of Materials.....	8vo,	4 00
* Michie's Elements of Analytical Mechanics.....	8vo,	4 00
Reagan's Locomotives: Simple, Compound, and Electric.....	12mo,	2 50
Reid's Course in Mechanical Drawing.....	8vo,	2 00
Text-book of Mechanical Drawing and Elementary Machine Design.....	8vo,	3 00
Richards's Compressed Air.....	12mo,	1 50
Robinson's Principles of Mechanism.....	8vo,	3 00
Ryan, Norris, and Hoxie's Electrical Machinery.....	8vo,	2 50
Sinclair's Locomotive-engine Running and Management.....	12mo,	2 00
Smith's Press-working of Metals.....	8vo,	3 00
Materials of Machines.....	12mo,	1 00
Spangler, Greene, and Marshall's Elements of Steam-engineering.....	8vo,	3 00
Thurston's Treatise on Friction and Lost Work in Machinery and Mill Work.....	8vo,	3 00
Animals as a Machine and Prime Motor, and the Laws of Energetics.....	12mo,	1 00
Warren's Elements of Machine Construction and Drawing.....	8vo,	7 50
Weisbach's Kinematics and the Power of Transmission. (Herrmann—Klein.).....	8vo,	5 00
Machinery of Transmission and Governors. (Herrmann—Klein.).....	8vo,	5 00
Wood's Elements of Analytical Mechanics.....	8vo,	3 00
Principles of Elementary Mechanics.....	12mo,	1 25
Turbines.....	8vo,	2 50
The World's Columbian Exposition of 1893.....	4to,	1 00

METALLURGY.

Egleston's Metallurgy of Silver, Gold, and Mercury:		
Vol. I.—Silver.....	8vo,	7 50
Vol. II.—Gold and Mercury.....	8vo,	7 50
** Iles's Lead-smelting. (Postage 9 cents additional.).....	12mo,	2 50
Keepe's Cast Iron.....	8vo,	2 50
Kunhardt's Practice of Ore Dressing in Europe.....	8vo,	1 50
Le Chatelier's High-temperature Measurements. (Boudouard—Burgess.).....	12mo,	3 00
Metcalf's Steel. A Manual for Steel-users.....	12mo,	2 60
Smith's Materials of Machines.....	12mo,	1 00
Thurston's Materials of Engineering. In Three Parts.....	8vo,	8 00
Part II.—Iron and Steel.....	8vo,	3 50
Part III.—A Treatise on Brasses, Bronzes, and Other Alloys and their Constituents.....	8vo,	2 50
Ulke's Modern Electrolytic Copper Refining.....	8vo,	3 00

MINERALOGY.

Barringer's Description of Minerals of Commercial Value.	Oblong, morocco,	2 50
Boyd's Resources of Southwest Virginia.....	8vo,	3 00
Map of Southwest Virginia.....	Pocket-book form,	2 00

Brush's Manual of Determinative Mineralogy. (Penfield.)	8vo,	4 00
Chester's Catalogue of Minerals	8vo, paper,	1 00
	Cloth,	1 25
Dictionary of the Names of Minerals	8vo,	3 50
Dana's System of Mineralogy	Large 8vo, half leather,	12 50
First Appendix to Dana's New "System of Mineralogy."	Large 8vo,	1 00
Text-book of Mineralogy	8vo,	4 00
Minerals and How to Study Them	12mo,	1 50
Catalogue of American Localities of Minerals	Large 8vo,	1 00
Manual of Mineralogy and Petrography	12mo,	2 00
Eakle's Mineral Tables. (<i>Shortly</i> .)		
Egleston's Catalogue of Minerals and Synonyms	8vo,	2 50
Hussak's The Determination of Rock-forming Minerals. (Smith.)	Small 8vo,	2 00
Merrill's Non-Metallic Minerals. (<i>Shortly</i> .)		
* Penfield's Notes on Determinative Mineralogy and Record of Mineral Tests.	8vo, paper,	0 50
Rosenbusch's Microscopical Physiography of the Rock-making Minerals.		
(Iddings.)	8vo,	5 00
* Tillman's Text-book of Important Minerals and Rocks	8vo,	2 00
Williams's Manual of Lithology	8vo,	3 00

MINING.

Beard's Ventilation of Mines	12mo,	2 50
Boyd's Resources of Southwest Virginia	8vo,	3 00
Map of Southwest Virginia	Pocket-book form,	2 00
* Drinker's Tunneling, Explosive Compounds, and Rock Drills.	4to, half morocco,	25 00
Eissler's Modern High Explosives	8vo,	4 00
Fowler's Sewage Works Analyses	12mo,	2 00
Goodyear's Coal-mines of the Western Coast of the United States	12mo,	2 50
Ihlseng's Manual of Mining	8vo,	4 00
** Iles's Lead-smelting. (Postage 9c. additional.)	12mo,	2 50
Kunhardt's Practice of Ore Dressing in Europe	8vo,	1 50
O'Driscoll's Notes on the Treatment of Gold Ores	8vo,	2 00
* Walke's Lectures on Explosives	8vo,	4 00
Wilson's Cyanide Processes	12mo,	1 50
Chlorination Process	12mo,	1 50
Hydraulic and Placer Mining	12mo,	2 00
Treatise on Practical and Theoretical Mine Ventilation	12mo	1 25

SANITARY SCIENCE.

Copeland's Manual of Bacteriology. (<i>In preparation</i> .)		
Folwell's Sewerage. (Designing, Construction and Maintenance.)	8vo,	3 00
Water-supply Engineering	8vo,	4 00
Fuertes's Water and Public Health	12mo,	1 50
Water-filtration Works	12mo,	2 50
Gerhard's Guide to Sanitary House-inspection	16mo,	1 00
Goodrich's Economical Disposal of Town's Refuse	Demy 8vo,	3 50
Hazen's Filtration of Public Water-supplies	8vo,	3 00
Kiersted's Sewage Disposal	12mo,	1 25
Leach's The Inspection and Analysis of Food with Special Reference to State Control. (<i>In preparation</i> .)		
Mason's Water-supply. (Considered Principally from a Sanitary Stand-point.) 3d Edition, Rewritten	8vo,	4 00
Examination of Water. (Chemical and Bacteriological.)	12mo,	1 25

Merriman's Elements of Sanitary Engineering	8vo, 2	00
Nichols's Water-supply. (Considered Mainly from a Chemical and Sanitary Standpoint.) (1883.)	8vo, 2	50
Ogden's Sewer Design	12mo, 2	00
* Price's Handbook on Sanitation	12mo, 1	50
Richards's Cost of Food. A Study in Dietaries	12mo, 1	00
Cost of Living as Modified by Sanitary Science	12mo, 1	00
Richards and Woodman's Air, Water, and Food from a Sanitary Standpoint.	8vo, 2	00
* Richards and Williams's The Dietary Computer	8vo, 1	50
Rideal's Sewage and Bacterial Purification of Sewage	8vo, 3	50
Turneaure and Russell's Public Water-supplies	8vo, 5	00
Whipple's Microscopy of Drinking-water	8vo, 3	50
Woodhull's Notes and Military Hygiene	16mo, 1	50

MISCELLANEOUS.

Barker's Deep-sea Soundings	8vo, 2	00
Emmons's Geological Guide-book of the Rocky Mountain Excursion of the International Congress of Geologists	Large 8vo, 1	50
Ferrel's Popular Treatise on the Winds	8vo, 4	00
Haines's American Railway Management	12mo, 2	50
Mott's Composition, Digestibility, and Nutritive Value of Food. Mounted chart.	1 25	
Fallacy of the Present Theory of Sound	16mo, 1	00
Ricketts's History of Rensselaer Polytechnic Institute, 1824-1894. Small 8vo, ...	3	00
Rotherham's Emphasized New Testament	Large 8vo, 2	00
Steel's Treatise on the Diseases of the Dog	8vo, 3	50
Totten's Important Question in Metrology	8vo, 2	50
The World's Columbian Exposition of 1893	4to, 1	00
Worcester and Atkinson. Small Hospitals, Establishment and Maintenance, and Suggestions for Hospital Architecture, with Plans for a Small Hospital.	12mo, 1	25

HEBREW AND CHALDEE TEXT-BOOKS.

Green's Grammar of the Hebrew Language	8vo, 3	00
Elementary Hebrew Grammar	12mo, 1	25
Hebrew Chrestomathy	8vo, 2	00
Gesenius's Hebrew and Chaldee Lexicon to the Old Testament Scriptures. (Tregelles.)	Small 4to, half morocco, 5	00
Letteris's Hebrew Bible	8vo, 2	25